
Projector

CP-WU8700/CP-WX8750/CP-X8800
CP-WU8600/CP-WX8650



User's Manual (detailed)
Network Guide

Thank you for purchasing this product.
This manual is intended to explain only the network function. For proper use of this product, please refer to this manual and the other manuals for this product.

⚠**WARNING** ►Before using this product, be sure to read all manuals for this product. After reading them, store them in a safe place for future reference.

Features

This projector has the network function that brings you the following main features.

- ✓ **Network Presentation** : allows the projector to project computer images transmitted through a network. (🕮*77*)
- ✓ **Web Control** : allows you to monitor and control the projector through a network from a computer. (🕮*37*)
- ✓ **My Image** : allows the projector to store up to four still images and project them. (🕮*81*)
- ✓ **Messenger** : allows the projector to display text sent from a computer through a network. (🕮*82*)
- ✓ **Network Bridge** : allows you to control an external device through the projector from a computer. (🕮*85*)

NOTE • The information in this manual is subject to change without notice.
• The illustrations in this manual are for illustrative purposes. They may differ slightly from your projector.
• The manufacturer assumes no responsibility for any errors that may appear in this manual.
• The reproduction, transfer or copy of all or any part of this document is not permitted without express written consent.

Contents

Caution 4

1. Network Function 5

1.1 Web Control 5
1.2 Network Presentation 6
1.3 My Image Function 7
1.4 Messenger Function 8
1.5 Network Bridge Function 9
1.6 Other Functions 10
1.6.1 E-mail Alerts 10
1.6.2 Projector Management using SNMP 10
1.6.3 Event Scheduling 10
1.6.4 Command Control via the Network 10

2. Connection to the network 11

2.1 System requirements 11
2.2 Connection via wired LAN 12
2.3 Connection setup of Wired LAN 12
2.4 Connection via wireless LAN 14
2.4.1 Connection in Simple Access Point Mode 15
2.4.2 Connection in Infrastructure Mode 16
2.5 Applications 18
2.6 NETWORK Menu 20

3. Web Control 37

3.1 Projector Web Control 39
3.1.1 Login 39
3.1.2 Network Information 40
3.1.3 Network Settings 41
3.1.4 Port Settings 46
3.1.5 Mail Settings 48
3.1.6 Alert Settings 50
3.1.7 Schedule Settings 52
3.1.8 Date/Time Settings 56
3.1.9 Security Settings 58
3.1.10 Projector Control 60
3.1.11 Remote Control 64
3.1.12 Projector Status 65
3.1.13 Network Restart 66
3.1.14 Connection Test 67

3.2 Crestron e-Control® 68
3.2.1 Main window 70
3.2.2 Tools window 72
3.2.3 Info window 74
3.2.4 Help Desk window 75
3.2.5 Emergency Alert 76
4. Network Presentation 77
4.1 Outline 77
4.2 Display Mode 78
4.2.1 Single PC mode 78
4.2.2 Multi PC mode 78
4.3 Multi Projector Mode 79
4.4 Moderator Control Mode 79
4.5 Port Number 80
5. My Image Function 81
6. Messenger Function 82
6.1 Outline 82
6.2 Supported Languages 83
6.3 Display Style 83
7. Network Bridge Function 85
7.1 Connecting devices 85
7.2 Communication setup 86
7.3 Communication port 86
7.4 Transmission method 87
7.4.1 HALF-DUPLEX 87
7.4.2 FULL-DUPLEX 88
8. Other Functions 89
8.1 E-mail Alerts 89
8.2 Projector Management using SNMP 92
8.3 Event Scheduling 94
8.4 Command Control via the Network 97
8.5 Crestron Connected™ 102
9. Troubleshooting 103
10. Warranty and after-sales service 112

Caution

To use the wireless network function of this projector, the designated USB wireless adapter sold as an option is required. For precautions according to the standards and laws, refer to the documents that come with the adapter.

[Restriction on plugging and unplugging the USB wireless adapter]

Before you insert or pull out the USB wireless adapter from the projector, turn off the power of the projector and pull out the power cord's plug from the outlet. Do not touch the USB wireless adapter that is connected to the projector while the projector is receiving AC power.

Do not use any extension cable or device when connecting the adapter to the projector.

[Security precautions when using wireless LAN]

It is recommended that security settings, such as SSID and ENCRYPTION, are specified when using wireless LAN communication. If the security settings are not specified, the contents may be intercepted or it may cause unauthorized access to the system. For details on wireless LAN security settings, refer to **3.1 Projector Web Control**.

⚠CAUTION

►The optional IEEE802.11b/g/n USB wireless adapter uses the 2.4GHz radio frequency band. You do not need a radio license to use the adapter, but you should be aware of the following:

- DO NOT USE NEAR THE FOLLOWING!
  - Microwave ovens
  - Industrial, scientific or medical devices
  - Designated low power radio stations
  - Premises radio stations

  Using the USB wireless adapter near the above may cause radio interference, which would result in a decrease in transmission speed or interruption, and even lead to malfunctioning of devices such as pacemakers.
- Depending on the location where the USB wireless adapter is used, radio wave interference may occur, which may result in a decrease in transmission speed or interruption in communication. In particular, please be aware that using the USB wireless adapter at locations where there is reinforced steel, other types of metals or concrete is likely to cause radio wave interference.
- Available Channels


  The USB wireless adapter uses the 2.4GHz radio frequency band, but depending on the country or region you are in, the channels that you can use might be limited. Please consult your dealer for information on the usable channels.
- Bringing the optional USB wireless adapter out of the country or region you reside in and using it there could lead to a violation of the radio laws of that country or region.

1. Network Function


This chapter describes the outline of network function.

1.1 Web Control

Connecting the projector and the computer via the network, remote control and status monitoring of the projector can be performed by Web browser.
Two types of interface, ”Projector Web Control” and “Crestron e-Control”, are available for this projector. (37)



Projector Web Control




Crestron e-Control

1.2 Network Presentation


The projector can display or play back the computer screen images and audio data that are transmitted through the network.
To use Network Presentation, an exclusive application, "LiveViewer" is required.
The following application is required to use Network Presentation.

OS	Application
Windows	LiveViewer
Mac OSX	LiveViewer
iOS(iPhone/iPad)	Projector Quick Connection
Android	Projector Quick Connection




1.3 My Image Function

The projector can display still images transferred via the network.
It is possible to allocate up to 4 image files.
MY IMAGE transmission requires an exclusive application for your computer.
Use the application to transfer the image data.




1.4 Messenger Function

The projector can display text data transferred via the network on the screen and play back audio data inside the projector.
It is possible to store up to 12 text data.



1.5 Network Bridge Function

This projector is equipped with the NETWORK BRIDGE function to perform mutual conversion of a network protocol and a serial interface.
By making use of the NETWORK BRIDGE function, a computer connected to the projector via wireless or wired LAN is able to control an external device via RS-232C communication using the projector as a network terminal.



1.6 Other Functions

1.6.1 E-mail Alerts

The projector can automatically send an alert message to the specified e-mail addresses when the projector detects a certain condition that is requiring maintenance or detected an error. (89)

1.6.2 Projector Management using SNMP

The SNMP (Simple Network Management Protocol) enables to manage the projector information, which is a failure or warning status, from the computer on the network. The SNMP management software will be required on the computer to use this function. (92)

1.6.3 Event Scheduling

The scheduling function enables to setup scheduled events including power on / power off. It enables to be “self-management” projector.
The schedule can be set in Projector Web Control or OPTION-SCHEDULE menu in the projector. (94)

1.6.4 Command Control via the Network

You can configure and control the projector via the network using RS-232C commands. (97)

2. Connection to the network

2.1 System requirements

The following equipments are required to connect the projector to your computer through the network.

■ **Common** The projector: 1 unit, Computer: 1 or more sets

■ **Connecting device for the projector and the computer**

1) For the wired connection ***1**
   LAN cable (CAT-5e or greater): 1 piece
2) For the wireless connection ***2**
   - Projector side
     IEEE802.11b/g/n USB wireless adapter (option : USB-WL-11N): 1 unit ***3**
   - Computer side
     IEEE802.11b/g/n wireless LAN equipment: 1 unit for each computer ***4**

***1:** The system for using the network function of the projector requires communication environment conforming to 100Base-TX or 10Base-T.

***2:** An access point is required when the wireless LAN connection is used as Infrastructure mode.

***3:** Available encryption methods are as follows. This product cannot be connected to the wireless network using other encryption method.

	Simple Access Point mode	Infrastructure mode
WPA2-PSK (AES)	✓	✓
WPA2-PSK (TKIP)	✓	✓
WPA-PSK (AES)	✓	✓
WPA-PSK (TKIP)	✓	✓
WEP 128bit	-	✓
WEP 64bit	-	✓

***4:** Depending on the type of wireless network device and computer you are using, the projector may not be able to communicate properly with your computer, even if the computer is equipped with a built-in wireless LAN function. To eliminate communication problems, use a Wi-Fi certified wireless network device.

■ Web browser
Web browser is required to be installed in your computer to use Web control.


■ Application
Exclusive applications are required to be installed in your computer to use Network Presentation, My Image and Messenger. (🕮*18*)

For Mac users: Mac OS does not support some applications. Refer to System Requirements for Applications (🕮*20*) first before setting up the connection.


NOTE • The network function is not available when STANDBY MODE is set to SAVING and the projector is in standby mode. Connect the projector to the network after setting STANDBY MODE to NORMAL. (🕮SETUP menu in the Operating Guide)

2.2 Connection via wired LAN


The connection via wired LAN is available. Set wired LAN for the projector by following the instructions of your network administrator when connecting to the existing network.



2.3 Connection setup of Wired LAN



1) Connect the projector to the computer via a hub with a LAN cable (CAT-5e or higher).
2) Press the **MENU** button on the remote control or the control panel of the projector.
   The MENU you last used will appear.
   Use the cursor button to select the following.
   EASY MENU > ADVANCED MENU > NETWORK > WIRED SETUP
3) Set the following items in WIRED SETUP.



- DHCP
- IP ADDRESS
- SUBNET MASK
- DEFAULT GATEWAY
- DNS SERVER

As for setting an IP address, refer to About IP address. (📖*13*)

Select APPLY, then press the **ENTER** button to reflect the settings.

[About IP address]
■ Setting manually
The Network address portion of the IP address setting on your computer must be the same as the setting on the projector. Also, the entire IP address on the computer must not overlap with that of the other devices on the same network, including the projector.

The projector's settings are as follows.
IP address: 192.168.1.254
Subnet mask: 255.255.255.0
(Network address: 192.168.1 in this case)
Therefore, specify the computer's IP address as follows.
IP address: 192.168.1.xxx (xxx shows decimal number.)
Subnet mask: 255.255.255.0
(Network address: 192.168.1 in this case)

For example
Select from 1 to 254 for "xxx" not duplicating with any other equipments.
In this case, since the IP address of the projector is "192.168.1.254", specify a setting between 1 to 253 for the computer.

■ Setting automatically
When a DHCP server exists in the connected network, it assigns an IP address to the projector and the computer automatically. If DHCP server is not available, set IP ADDRESS, SUBNET MASK and DEFAULT GATEWAY.

NOTE
• Although **HDBaseT™** and **LAN** port can be used for wired LAN, they cannot be used simultaneously. Connect LAN cable to the port set in WIRED NETWORK on NETWORK menu.
• The same network address cannot be used for both wireless LAN and wired LAN.
• If the projector and the computer exist in the same network (i.e., same network address), you can leave the default gateway field blank.
• When the projector and the computer exist in different networks, the default gateway must be set. Consult to the network administrator in detail.

2.4 Connection via wireless LAN

Connection via wireless LAN is available with option parts, USB wireless adapter (USB-WL-11N).
Wireless LAN has two types of connection, Simple Access Point and Infrastructure.



Fig. 2.4.a Without an access point communication (Simple Access Point)




Fig. 2.4.b With an access point communication (Infrastructure)

* SIMPLE ACCESS POINT is a mode which connects to computers directly. This projector can assign IP addresses to up to 11 devices.
* Infrastructure is one of the wireless LAN communication methods with having an access point to communicate. If communicating with existing network, consult with your network administrator.

NOTE

• Network settings can also be changed in Network Settings of Projector Web Control.
• Wireless LAN initial settings for the projector are as follows.
  Mode: Simple Access Point
  DHCP: Off
  IP address: 192.168.10.1
  Subnet Mask: 255.255.255.0
  Default Gateway: 0.0.0.0
  DNS Server: 0.0.0.0
  SSID: SimpleAccessPoint ※
  SSID Broadcast: On
  Encryption: Off
  Channel: 11
  ※ Change default setting before use not to overlap.
• The same network address cannot be used for both wireless LAN and wired LAN.
• Communication speed of the projector may be deteriorated in SIMPLE ACCESS POINT mode depending on the number of connected devices.
• Network communication cannot be available between the devices connected to the projector in SIMPLE ACCESS POINT mode.


2.4.1 Connection in Simple Access Point Mode

Set the following when connecting the projector and the computer in Simple Access Point mode.


Projector setting

[Restriction on plugging and unplugging the USB wireless adapter]
Before you insert or pull out the USB wireless adapter from the projector, turn off the power of the projector and pull out the power cord's plug from the outlet. Do not touch the USB wireless adapter that is connected to the projector while the projector is receiving AC power.
Do not use any extension cable or device when connecting the adapter to the projector.

1) Attach the USB wireless adapter to the **WIRELESS** port of the projector.
2) Turn on the projector.
3) Press the **MENU** button on the remote control or the control panel of the projector.
   The MENU you last used will appear.



   Use the cursor button to select the following.
   EASY MENU > ADVANCED MENU > NETWORK > WIRELESS SETUP
4) Set the following items in WIRELESS SETUP.
   · MODE: SIMPLE ACCESS POINT
   · IP ADDRESS
   · SSID
   · SSID BROADCAST
   · ENCRYPTION
   · CH



Select APPLY, then press the **ENTER** button to reflect the settings.

About network settings

· The fourth octet of the projector's IP address is fixed to 1.
· Subnet mask of the projector is fixed to 255.255.255.0.

Computer setting

1) The DHCP server function of the projector is always enabled. Enable the DHCP setting of the computer.
2) Select SSID set for the projector by following the procedure of wireless connection of the computer. Enter encryption key by following the computer's instruction if it is encrypted.


NOTE • As for the procedure of setting network and wireless connection for the computer, refer to the manual of computer or wireless LAN device.

2.4.2 Connection in Infrastructure Mode


Set the following when connecting the projector and the computer in Infrastructure mode.

[Restriction on plugging and unplugging the USB wireless adapter]
Before you insert or pull out the USB wireless adapter from the projector, turn off the power of the projector and pull out the power cord's plug from the outlet. Do not touch the USB wireless adapter that is connected to the projector while the projector is receiving AC power.
Do not use any extension cable or device when connecting the adapter to the projector.

1) Attach the USB wireless adapter to the **WIRELESS** port of the projector.
2) Turn on the projector.
3) Press the **MENU** button on the remote control or the control panel of the projector.
   The MENU you last used will appear.



   Use the cursor button to select the following.
   EASY MENU > ADVANCED MENU > NETWORK > WIRELESS SETUP
4) Set the following items in WIRELESS SETUP.
   · MODE: INFRASTRUCTURE
   · DHCP
   · IP ADDRESS
   · SUBNET MASK
   · DEFAULT GATEWAY
   · DNS SERVER
   · SSID
   · ENCRYPTION



   As for setting an IP address, refer to About IP address. (📖13)

Select APPLY, then press the **ENTER** button to reflect the settings.

Connection in Infrastructure Mode (continued)

SSID SCAN LIST function

The connection can be set up by selecting from SSID SCAN LIST without setting SSID and ENCRYPTION in WIRELESS SETUP. The procedure of connecting by SSID SCAN LIST is as follows.

1) Select SSID SCAN LIST in WIRELESS SETUP on NETWORK menu.
   The list of SSID in wireless network is displayed.
2) Select SSID in wireless network that you want to connect in SSID SCAN LIST.
   The display to enter the encryption key appears if it is encrypted.
   Enter the encryption key by using software keyboard.
3) The icon indicating connected ( ) is displayed in SSID SCAN LIST screen when the connection is complete.

NOTE

- Transmission speed may be slow depending on the settings of an access point.
- If the projector and the computer exist in the same network (i.e., same network address), you can leave the default gateway field blank.
- When the projector and the computer exist in different networks, the default gateway must be set. Consult with the network administrator in detail.
- Set wireless LAN for the projector by following the instructions of your network administrator when connecting to the existing network.
- Open System Authentication is used for WEP encryption, and Shared Key Authentication is not supported. The authentication with an access point succeeds and it is regarded that the connection is established normally even when entering illegal encryption key due to Open System Authentication, but data cannot actually be transmitted.
- IP ADDRESS, SUBNET MASK, and DEFAULT GATEWAY should be set in advance when DHCP is set to OFF.

2.5 Applications

The latest version of the application software can be downloaded from the website below.

http://www.hitachi-america.us/projectors
http://www.hitachidigitalmedia.com/
http://www.hitachi-dm.cn/
http://www.hitachi.co.jp/proj/

For iOS/Android Network Presentation software, refer to the URL below for details and downloads of Projector Quick Connection.

http://www.hitachi.co.jp/Prod/vims/proj/en/
http://www.hitachi.co.jp/proj/


[System Requirements for Applications]

Application	Hardware and Software
LiveViewer	[Windows] OS: Windows Vista® (Service Pack 1 or later) Windows 7 Windows 8/8.1 Graphic card: VGA: 640x480 or higher (recommended XGA: 1024x768) CPU: Pentium 4 (2.8 GHz or higher) Hard disk space: 100MB or higher

[System Requirements for Applications] (continued)

Application	Hardware and Software
LiveViewer	[Mac] Mac OSX 10.5 Mac OSX 10.6 Mac OSX 10.7 Mac OSX 10.8 Hard disk space: 15MB or higher **NOTE** • Only for Intel version. Power Mac is not supported. • LiveViewer for MAC is not included in the bundled CD-ROM. Download it from the website.
Projector Quick Connection	[iOS] iOS 6 or later [Android] Android OS 4.0 or later
Projector Image Tool (PJImg)	OS: Windows Vista® Windows 7 Windows 8/8.1 CPU: Pentium 3 (500MHz or higher) Hard disk space: 20MB or higher
Projector Messenger Tool (PJMessenger)	OS: Windows Vista® Windows 7 Windows 8/8.1 CPU: Pentium 3 (500MHz or higher) Hard disk space: 20MB or higher

2.6 NETWORK Menu





Remember that incorrect network settings on this projector may cause trouble on the network. Be sure to consult with your network administrator before connecting to an existing access point on your network. Select “NETWORK” from the main menu to access to the following functions.
Select an item using the ▲/▼ cursor buttons on the projector or remote control, and press the ► cursor button on the projector or remote control, or **ENTER** button on the remote control to execute the item. Then perform it according to the following table.

NOTE • When you use wired LAN, first select which function to use, LAN or HDBaseT™, in WIRED NETWORK menu.
• To use the wireless network function of this projector, the designated USB wireless adapter sold as an option is required. Do not use any extension cable or device when connecting the adapter to the projector.
• The projector does not allow both wireless and wired LAN to be connected to the same network.
• Do not set the same network address for both wireless and wired LAN.
• If you do not use SNTP, then you must set the DATE AND TIME during the initial installation.
• The network function is not available when STANDBY MODE is set to SAVING and the projector is in standby mode. Connect the projector to the network after setting STANDBY MODE to NORMAL. (📖SETUP menu in the Operating Guide)

Item	Description
PROJECTOR NAME	Any name can be set to the projector to identify it on the network.  (1) Select the PROJECTOR NAME and press the ► button. The PROJECTOR NAME dialog will be displayed. Use displayed software keyboard to enter PROJECTOR NAME. DELETE : Deletes one character. CLEAR ALL: Deletes all characters. CANCEL : Goes back to network menu after discarding the entered characters. OK : Goes back to network menu after saving the entered characters. (2) The current PROJECTOR NAME will be displayed on the first 3 lines. Particular projector name is pre-assigned by default. Use the **ENTER** or **INPUT** button to select and enter characters. To erase 1 character at one time, press the **RESET** button or press the ◄ and **INPUT** button at the same time. Also if you move the cursor to DELETE or CLEAR ALL on screen and push the **ENTER** or **INPUT** button, 1 character or all characters will be erased. Up to 64 characters can be input for the PROJECTOR NAME.  (3) To change an already inserted character, move the cursor to one of the first 3 lines, and move the cursor on the character to be changed. After pressing the **ENTER** or **INPUT** button, the character is selected. Then, follow the same procedure as described at the item (2) above.  (4) To finish entering text, move the cursor to the OK on screen and press the ►, **ENTER** or **INPUT** button. To revert to the previous PROJECTOR NAME without saving changes, move the cursor to the CANCEL on screen and press the ◄, **ENTER** or **INPUT** button.


(continued on next page)

<table>
<tr><th>Item</th><th colspan="2">Description</th></tr>
<tr><td rowspan="2">WIRELESS SETUP</td><td colspan="2">Configures wireless network.
Setting values are saved after selecting "APPLY".


NOTE
• Setting values are not saved if Menu dissapears before selecting "APPLY".
• Be sure to execute "APPLY" after changing the settings.</td></tr>
<tr><td>SSID SCAN LIST</td><td>Searches available wireless network and displays the list of SSID.
You can select SSID to connect from the list.
(1) SSID on available wireless network is displayed after selecting SSID SCAN LIST and press the ► button.


NOTE
• The wireless network using the encryption method not supported by the projector is not displayed in the search list.
• A network device of AdHoc doesn't be displayed on SSID SCAN LIST.</td></tr>
</table>

(continued on next page)


<table>
<tr><th>Item</th><th>Description</th></tr>
<tr><td>WIRELESS SETUP (continued)</td><td>SSID SCAN LIST (continued)</td><td>
<table>
<tr><th>Icon</th><th>Description</th></tr>
<tr><td></td><td>The projector is connecting to the wireless network.</td></tr>
<tr><td></td><td>The wireless network is encrypted.</td></tr>
<tr><td></td><td>The intensity of radio wave.</td></tr>
</table>
(2) Select SSID that you want to connect and press the ► or ENTER button. The display to enter the encryption key appears if SSID is encrypted. Enter the characters by using software keyboard.
Move the cursor to OK and press the ►, ENTER or INPUT button after entering.


NOTE
If you select the [HIDE THE CHARACTERS] checkbox, the characters are hidden.
</td></tr>
</table>

(continued on next page)

Item		Description
WIRELESS SETUP (continued)	**SSID SCAN LIST (continued)**	(3) The OSD below is displayed while the connection is in progress. CONNECTING... The keys other than Reset button are not available while the connection is in progress. The connection process is interrupted when pressing the Reset button. The OSD below is displayed when the connection process is complete. SUCCEEDED : Connection succeeded The message below is displayed when the connection is not established correctly. FAILED : Connection failed ENCRYPTION LOCK : Encryption Lock enabled **NOTE** • Encryption settings cannot be changed when encryption lock is enabled in Network Settings – Wireless Setup in Projector Web Control. Refer to Encryption Lock. (📖42) • Open System Authentication is used for WEP encryption, and Shared Key Authentication is not supported. The authentication with an access point is succeeded and it is regarded that the connection is established normally even when entering illegal encryption key due to Open System Authentication, but data cannot actually be transmitted. (4) The icon indicating the connection status () is displayed in SSID SCAN LIST when the connection is complete.

(continued on next page)

<table>
<tr><th>Item</th><th colspan="2">Description</th></tr>
<tr><td rowspan="3">WIRELESS SETUP (continued)</td><td>SSID SCAN LIST (continued)</td><td>

This function is not available in SIMPLE ACCESS POINT mode.</td></tr>
<tr><td>MODE</td><td>Switches between SIMPLE ACCESS POINT and INFRASTRUCTURE.
Select the mode of the network communication system. Select according to the settings of your computer.
SIMPLE ACCESS POINT ⇔ INFRASTRUCTURE
To save the setting, press the ► button.

NOTE
• The setting changed before switching MODE without selecting "APPLY" is cancelled.
• When switching MODE, it takes 60 seconds to be able to use wireless LAN. In the meantime, the operating speed of the projector may be decreased and NETWORK INFORMATION may not be displayed correctly.</td></tr>
<tr><td>DHCP</td><td>Configures whether IP address is automatically obtained or not.
Use the ▲/▼ buttons to turn DHCP on/off.
ON ⇔ OFF
This function is not available in SIMPLE ACCESS POINT mode.</td></tr>
</table>

(continued on next page)

Item		Description
WIRELESS SETUP (continued)	IP ADDRESS	[SIMPLE ACCESS POINT] Refer to "Connection in Simple Access Point Mode".(15) [INFRASTRUCTURE] Configures the IP address when DHCP is disabled. Enter the IP ADDRESS. This function can only be used when DHCP is set to OFF.
	SUBNET MASK	[SIMPLE ACCESS POINT] This setting is fixed to 255.255.255.0. [INFRASTRUCTURE] Configures the subnet mask when DHCP is disabled. Enter the SUBNET MASK. This function can only be used when DHCP is set to OFF.
	DEFAULT GATEWAY	Configures the default gateway when DHCP is disabled. Enter the DEFAULT GATEWAY address. This function can only be used when DHCP is set to OFF. This function is not available in SIMPLE ACCESS POINT mode.
	DNS SERVER	Configures the DNS server address. Enter the DNS server address. This function is not available in SIMPLE ACCESS POINT mode. **NOTE** This setting cannot be obtained automatically.


(continued on next page)

Item		Description
WIRELESS SETUP (continued)	**SSID**	Configures SSID for wireless network.  [SIMPLE ACCESS POINT] Enter SSID by using software keyboard. Refer to PROJECTOR NAME (📖*21*) for how to use software keyboard. Default setting of SSID in Simple Access Point mode is [SimpleAccessPoint]. Change default setting before use not to overlap. [INFRASTRUCTURE] Select one of the DEFAULT (#1~#4) and press ► or **ENTER** button. **To adjust CUSTOM** Press the ► or **ENTER** button when the # 5 CUSTOM is selected. The SSID #5 CUSTOM menu will be appeared. Enter SSID by using software keyboard. Refer to PROJECTOR NAME (📖*21*) for how to use software keyboard.

(continued on next page)

Item		Description
WIRELESS SETUP (continued)	**SSID BROADCAST**	Configures SSID BROADCAST. Set this function to OFF when making SSID of a projector not to be displayed in wireless connection list of the computer.
	ENCRYPTION	Select the encryption method to be used. WPA2-PSK(AES) ⇔ WPA2-PSK(TKIP) ⇕ ⇕ OFF WPA-PSK(AES) ⇕ ⇕ WEP 64bit⇔WEP 128bit⇔WPA-PSK(TKIP) WEP 64bit and WEP 128bit are available only in INFRASTRUCTURE mode. It is required to enter the encryption key when selecting the encryption method other than OFF and pressing the ► button. **NOTE** • WPA2-PSK (AES) is recommended for encryption method of IEEE802.11n. Transmission speed in IEEE802.11n may be slow when other encryption method (WEP, WPA-PSK (TKIP), WPA2-PSK (TKIP)). Change the setting to “AES” if encryption other than “AES” is set. • Encryption method not included in the selected item cannot be available.
	CH	Select the channel of the wireless LAN to be used while MODE (📖25) is set to SIMPLE ACCESS POINT. The channels 1 to 11 are available. To save the setting, press the ► button. • The available channels vary depending on a country.

(continued on next page)

<table>
<tr><th>Item</th><th colspan="2">Description</th></tr>
<tr><td rowspan="5">WIRED SETUP</td><td colspan="2">Configures wired network.
Setting values are saved after selecting "APPLY".


NOTE
• Setting values are not saved if Menu dissapears before selecting "APPLY".
• Be sure to execute "APPLY" after changing the settings.</td></tr>
<tr><td>DHCP</td><td>Configures whether IP address is automatically obtained or not.
Use the ▲/▼ buttons to turn DHCP on/off.
ON ⇔ OFF</td></tr>
<tr><td>IP ADDRESS</td><td>Configures the IP address when DHCP is disabled.
Enter the IP ADDRESS.
This function can only be used when DHCP is set to OFF.</td></tr>
<tr><td>SUBNET MASK</td><td>Configures the subnet mask when DHCP is disabled.
Enter the SUBNET MASK.
This function can only be used when DHCP is set to OFF.</td></tr>
<tr><td>DEFAULT GATEWAY</td><td>Configures the default gateway when DHCP is disabled.
Enter the DEFAULT GATEWAY address.
This function can only be used when DHCP is set to OFF.</td></tr>
<tr><td>DNS SERVER</td><td>Configures the DNS server address.
Enter the DNS server address.
NOTE
This setting cannot be obtained automatically.</td></tr>
</table>

(continued on next page)

<table>
<tr><th>Item</th><th colspan="2">Description</th></tr>
<tr><td rowspan="2">NETWORK INFORMATION</td><td colspan="2">Selecting this item displays the dialog for viewing the wireless and wired LAN settings. Use the ▲/▼ buttons to switch the page.
The first page shows the wireless LAN settings. The second page is for the wired LAN settings, and the third page is for common setting item.</td></tr>
<tr><td>WIRELESS INFORMATION</td><td>The following information is displayed.
· PASSCODE
· MODE
· IP ADDRESS
· SUBNET MASK
· DEFAULT GATEWAY
· DNS SERVER
· MAC ADDRESS
· SSID
· SSID BROADCAST
· ENCRYPTION
· CH
· SPEED

Passcord supports the connection between the projector and the computer when using Network Presentation. Refer to Network Presentation (🕮77) for the details.

NOTE • IP ADDRESS, SUBNET MASK and DEFAULT GATEWAY indicate “0.0.0.0” in the following condition.
(1) The USB wireless adapter is not inserted into the projector.
(2) DHCP is ON and the projector does not get address from DHCP server.
• Nothing (blank) is shown in the CH and SPEED fields if the USB wireless adapter is not inserted.</td></tr>
</table>


(continued on next page)

Item	Description	
NETWORK INFORMATION (continued)	**WIRED INFORMATION**	The following information is displayed. · PASSCODE · IP ADDRESS · SUBNET MASK · DEFAULT GATEWAY · DNS SERVER · MAC ADDRESS Passcord enables the projector and the computer to be connected to the network easily when using Network Presentation. Refer to Network Presentation (77) for details. **NOTE** • IP ADDRESS, SUBNET MASK and DEFAULT GATEWAY indicate “0.0.0.0” when DHCP is ON and the projector has not gotten address from DHCP server.
	OTHER INFORMATION	The following information is displayed. · PROJECTOR NAME · DATE AND TIME · SNTP SERVER · TIME DIFFERENCE • PROJECTOR NAME and SNTP SERVER may appear truncated if they are too long.

(continued on next page)

Item		Description
SNTP SETUP	**SNTP SERVER**	When you get the time via the network, specify SNTP server with IP address or domain name. Up to 255 characters can be entered for domain name. They are entered by using software keyboard. Refer to PROJECTOR NAME(21) for how to use software keyboard. **NOTE** Set the time difference when using SNTP.
	TIME DIFFERENCE	Enter the time difference. Set the same time difference as the one set on your computer. If unsure, consult your network administrator. Use the ► button to return to the menu after setting the TIME DIFFERENCE.

(continued on next page)

Item	Description
MY IMAGE	Selecting this item displays the MY IMAGE menu. Use the application to transfer the image data. It can be downloaded from the web site.  Refer to 5. My Image Function (81) for the details of MY IMAGE. Select an item of still image by the MY IMAGE and the ► or **ENTER** button to display the image. • The item without stored image cannot be selected. • Each image name is displayed in 16 characters or less. **To switch the image displayed** Use the ▲/▼ buttons. **To return to the menu** Press the ◄ button on the remote control. **To erase the displayed image and its source file in the projector.** (1) Press the **RESET** button on the remote control while displaying an image to display the MY IMAGE DELETE menu.  (2) Press the ► button to erase. To stop erasing, press the ◄ button.


(continued on next page)

Item		Description
EXTERNAL CONTROL	AMX D.D. (AMX Device Discovery)	Use the ▲/▼ buttons to turn the AMX Device Discovery on/off. ON ⇔ OFF When ON is selected, the projector can be detected by controllers of AMX connected to the same network. For the details of AMX Device Discovery, visit the AMX web site. URL: http://www.amx.com/
	CRESTRON	Use the ▲/▼ buttons to turn the Crestron Connected™ on/off. ON ⇔ OFF When ON is selected, controlling and managing the projector can be performed by using the controllers of Crestron connected to the same network. For the details of Crestron Connected™, visit the following web site. URL: http://www.crestron.com/
	EXTRON	Use the ▲/▼ buttons to turn the Extron on/off. ON ⇔ OFF When ON is selected, the controllers of Extron connected via HDBaseT™ can detect the projector. For the details of Extron, visit the following web site. URL: http://www.exrtron.com/ **NOTE** • This item is enabled only when HDBaseT is selected in WIRED NETWORK.

(continued on next page)

Item	Description	
PRESENTATION	To use Network Presentation, an exclusive application is required. It can be installed from the bundled application CD. You can also download the latest version and relevant information from the Hitachi website. Refer to 4. Network Presentation (🕮77) for the details of Network Presentation.	
	QUIT PRESENTER MODE	If you set a computer to the Presenter mode while its image is projected, the projector is occupied by the computer and access from any other computer is blocked. Use this function to quit the Presenter mode and allow other computers to access the projector. Select this item to display a dialog. Press the ► button to choose OK in the dialog. The Presenter mode is cancelled and a message is displayed indicating the result.
	MULTI PC MODE	If you set one or more computers to the Multi PC mode and send their images to the projector, you can select the display mode on the projector from two options below. - Single PC mode: displays the image of the selected computer on full screen. - Multi PC mode: displays the images sent from up to four computers on screen that is divided into quarter sections. Select this item to display a dialog. Use the dialog to change the display mode as explained below. • To change from Multi PC mode to Single PC mode, select one of computers in the dialog using the ▲/▼/◄/► buttons and press the **ENTER** or **INPUT** button. Press the ► button to choose OK, and then press **ENTER** or **INPUT** again. The image for the selected computer is displayed on full screen. (continued on next page)

(continued on next page)


<table>
<tr><th>Item</th><th colspan="2">Description</th></tr>
<tr><td rowspan="2">PRESENTATION
(continued)</td><td>MULTI PC
MODE
(continued)</td><td>• To change from Single PC mode to Multi PC mode, press the ► button to choose OK in the dialog and press the ENTER or INPUT button. The display mode is changed.
• The Presenter mode setting of the selected computer becomes valid when the display mode is changed to Single PC mode. Also, the Presenter mode setting becomes invalid when the display mode is changed to Multi PC mode, regardless of the setting on the computers.

</td></tr>
<tr><td>DISPLAY
USER NAME</td><td>Selecting this item displays the user name. This function helps you identify from which computer the current image is sent.</td></tr>
<tr><td>WIRED
NETWORK</td><td colspan="2">Selects whether to use LAN or HDBaseT™ port.
LAN ⇔ HDBaseT
NOTE
Only either LAN or HDBaseT port can be used for the connection to the network. Switch it according to the environment.</td></tr>
</table>

3. Web Control

You can adjust or control the projector via a network from a web browser on a computer connected to the same network.

■Projector Web Control

You can control the projector, collect the status such as lamp time, and set e-mail or schedule, etc. in Projector Web Control.



Recommended web browser


・Internet Explorer® 8/ 9/ 10/ 11

NOTE

- Web browsers other than recommended ones may not work.
- If JavaScript® is disabled in your web browser configuration, you must enable JavaScript® in order to use the projector web pages properly. See the Help files for your web browser for details on how to enable JavaScript®.
- It is recommended that all web browser updates are installed.
- If data is transferred via wireless and wired LAN at the same time, the projector may not process the data correctly.

■Crestron e-Control

Crestron e-Control® is a control interface using a web browser provided by Crestron Electronics, Inc..
Crestron e-Control® can control and monitor the projector.




(continued on next page)

NOTE • Crestron e-Control® is created using Flash®. You need to install Adobe® Flash® Player on your computer to use Crestron e-Control®. Crestron e-Control® is not displayed in a web browser that does not support Flash®.
• In any of the following cases, the selection window does not appear but the Login window of the Projector Web Control is displayed.
- Network Settings - Other Setup - Crestron e-Control is "Disable" (📖*45*)
- Network Settings - Common Setup - Crestron is "OFF" (📖*42*)
- NETWORK menu - EXTERNAL CONTROL - CRESTRON is "OFF" (📖*34*)

Refer to the following for configuring or controlling the projector via a web browser. Make sure that your computer and the projector is connected via network, and then start Web browser.
Enter the projector's IP address into URL input box of the Web browser as the example below, and then press the Enter key or → button.

Example: If the IP address of the projector is set to **192.168.1.10**:
Enter "**http://192.168.1.10/**" into the address bar of the web browser and press the Enter key or click → button.

If a correct URL is input, and the projector and your computer are connected to the same network correctly, the selection window will be displayed.




NOTE • Do not control the projector with the projector's menu or remote control, and via Web Control at the same time. It may cause some operational errors in the projector.
• The language used on the Projector Web Control is the same as that of the OSD on the projector. If you want to change it, you need to change the OSD language on the projector. (📖SCREEN menu in the Operating Guide)

3.1 Projector Web Control

3.1.1 Login

To use the Projector Web Control function, you need to login with your user name and password.




Login window

Below are the factory default settings for user name and password.

User name	Administrator
Password	<blank>

Enter your user name and password, and then click the **[OK]**.
If you login successfully, the screen below will be displayed.


Main menu



Click the desired operation or configuration item on the main menu.

3.1 Projector Web Control (continued)

3.1.2 Network Information




Displays the projector's current network configuration settings.

Item		Description
Common Information		Displays information common to both wireless and wired LAN.
	Projector Name	Displays the projector name settings.
Wireless Information		Displays the current settings of wireless LAN.
	Mode	Displays the mode of wireless LAN communication.
	DHCP	Displays the DHCP setting.
	IP Address	Displays the IP address.
	Subnet Mask	Displays the subnet mask.
	Default Gateway	Displays the default gateway.
	DNS Server Address	Displays the DNS server address.
	MAC Address	Displays the MAC address.
	SSID	Displays the SSID used by the projector.
	SSID Broadcast	Displays the SSID Broadcast used by the projector.
	Encryption	Displays the data encryption setting.
	Ch	Displays the channel used for wireless LAN.
	Speed	Displays the current wireless LAN transmission speed.
Wired Information		Displays the current wired LAN settings.
	DHCP	Displays the DHCP setting.
	IP Address	Displays the IP address.
	Subnet Mask	Displays the subnet mask.
	Default Gateway	Displays the default gateway.
	DNS Server Address	Displays the DNS server address.
	MAC Address	Displays the MAC address.

3.1 Projector Web Control (continued)

3.1.3 Network Settings



Displays and configures network settings.

Item		Description
Common Setup		Configures the settings common to wireless and wired LAN.
	Projector Name	Configures the name of the projector. The length of the Projector Name can be up to 64 alphanumeric characters. Only alphabets, numbers and following symbols can be used. !"#$%&'()*+,-./:;<=>?@[\]^_`{|}~ and space. Particular projector name is pre-assigned by default.
	sysLocation (SNMP)	Configures the location to be referred to when using SNMP. The length of the sysLocation can be up to 255 alphanumeric characters. Only numbers '0-9', alphabet 'a-z' and 'A-Z' can be used.
	sysContact (SNMP)	Configures the contact information to be referred to when using SNMP. The length of the sysContact can be up to 255 alphanumeric characters. Only numbers '0-9', alphabet 'a-z' and 'A-Z' can be used.
	AMX D.D. (AMX Device Discovery)	Configures the AMX Device Discovery setting to detect the projector from the controllers of AMX connected to the same network. For the details of AMX Device Discovery, visit the AMX web site. URL: http://www.amx.com

(continued on next page)

3.1 Projector Web Control - Network Settings (continued)

Item		Description
Common Setup (continued)		Configures the settings common to wireless and wired LAN.
	Crestron	Configures the Crestron setting to detect the projector from the controllers of Crestron connected to the same network. For the details of Crestron, visit the Crestron web site. URL: http://www.crestron.com
	Extron	Configures the Extron setting to detect the projector from the controllers of Extron connected to the same network via **HDBaseT™** port. For the details of Extron, visit the Extron web site. URL: http://www.extron.com **NOTE** • This item is enabled only when HDBaseT is selected in WIRED NETWORK. (36)
Wireless Setup		Configures the wireless LAN settings.
	Mode	Select "Simple Access Point" or "Infrastructure". **NOTE** • When switching MODE, it takes 60 seconds to be able to use wireless LAN. In the meantime, the operating speed of the projector may be decreased and NETWORK INFORMATION may not be displayed correctly.
	Encryption Lock	Permits or inhibits changes of the following settings related to wireless connection. · Mode · SSID · SSID Broadcast · Encryption · Encryption key (WEP key, WPA passphrase) When Encryption Lock is set to ON, these settings cannot be changed by the menu of the projector. **NOTE** • If Encryption Lock is ON, wireless connection is performed only when it can be connected without changing the current settings.

(continued on next page)

3.1 Projector Web Control - Network Settings (continued)

Item	Description
Wireless Setup (continued)	Configures the wireless LAN settings.
Simple Access Point settings	Configures Simple Access Point mode.
IP Configuration	Configures network settings.
IP Address	Configures the IP address.
Subnet Mask	Subnet mask of the projector is fixed to 255.255.255.0.
SSID	Input SSID. The maximum number of input characters is 32. Only alphabets, numbers and the following symbols can be used. !"#$%&'()*+,-./:;<=>?@[\]^_`{|}~ and space. Default setting of SSID in Simple Access Point mode is [SimpleAccessPoint]. Change default setting before use not to overlap.
SSID Broadcast	Select SSID Broadcast. Set this function to OFF when making SSID of a projector not to be displayed in wireless connection list of the computer.
Encryption	Select data encryption method.
WPA Passphrase	Input WPA Passphrase. Available number of input characters is 8 to 63. Only alphabets, numbers and the following symbols can be used. !"#$%&'()*+,-./:;<=>?@ [\]^_`{|}~ and space
Ch	Select from “1” to “11”, a channel to use in the Simple Access Point mode. **NOTE** • The channels may vary depending on the country. In addition, depending on the country or region, it may be required to use a wireless network card that conforms to the standards in the respective country or region.

(continued on next page)

3.1 Projector Web Control - Network Settings (continued)

<table>
<tr><th colspan="5">Item</th><th>Description</th></tr>
<tr><td colspan="5">Wireless Setup (continued)</td><td>Configures the wireless LAN settings.</td></tr>
<tr><td></td><td colspan="4">Infrastructure settings</td><td>Configures Infrastructure mode.</td></tr>
<tr><td></td><td></td><td colspan="3">IP Configuration</td><td>Configures network settings.</td></tr>
<tr><td></td><td></td><td></td><td colspan="2">DHCP ON</td><td>Enables DHCP.</td></tr>
<tr><td></td><td></td><td></td><td colspan="2">DHCP OFF</td><td>Disables DHCP.</td></tr>
<tr><td></td><td></td><td></td><td></td><td>IP Address</td><td>Configures the IP address when DHCP is disabled.</td></tr>
<tr><td></td><td></td><td></td><td></td><td>Subnet Mask</td><td>Configures the subnet mask when DHCP is disabled.</td></tr>
<tr><td></td><td></td><td></td><td></td><td>Default Gateway</td><td>Configures the default gateway when DHCP is disabled.</td></tr>
<tr><td></td><td></td><td colspan="3">DNS Server Address</td><td>Configures the DNS server address.</td></tr>
<tr><td></td><td></td><td colspan="3">SSID</td><td>Select an SSID from the list.
If you require to set your unique SSID, select [Custom], then set your own SSID following the rules below.
The maximum number of input characters is 32.
Only alphabets, numbers and the following symbols can be used.
!"#$%&'()*+,-./:;<=>?@[\]^_`{|}~ and space.</td></tr>
<tr><td></td><td></td><td colspan="3">Encryption</td><td>Select data encryption method.</td></tr>
<tr><td></td><td></td><td colspan="3">WEP Key</td><td>Input the WEP key.
Either ASCII characters or hexadecimal numbers can be used during WEP key input. However, you cannot use a combination of both.The length of the key is defined as follows according to the WEP and character formats.
<table>
<tr><th>Encryption</th><th>ASCII characters</th><th>HEX numbers</th></tr>
<tr><td>WEP 64bit</td><td>5 characters</td><td>10 characters</td></tr>
<tr><td>WEP 128bit</td><td>13 characters</td><td>26 characters</td></tr>
</table></td></tr>
<tr><td></td><td></td><td colspan="3">WPA Passphrase</td><td>Input WPA Passphrase.
Available number of input characters is 8 to 63. Only alphabets, numbers and the following symbols can be used.
!"#$%&'()*+,-./:;<=>?@ [\]^_`{|}~ and space</td></tr>
</table>

(continued on next page)

3.1 Projector Web Control - Network Settings (continued)


Item	Description
Wired Setup	Configures the wired LAN settings.
IP Configuration	Configures network settings.
DHCP ON	Enables DHCP.
DHCP OFF	Disables DHCP.
IP Address	Configures the IP address when DHCP is disabled.
Subnet Mask	Configures the subnet mask when DHCP is disabled.
Default Gateway	Configures the default gateway when DHCP is disabled.
DNS Server Address	Configures the DNS server address.
Other Setup	Configures other network settings.
Crestron e-Control	Set whether or not to use Crestron e-Control®. If you choose Disable, not the selection window but the Login window of Projector Web Control will be displayed at first.

Click the **[Apply]** button to save the settings.

NOTE • The new configuration settings are activated after restarting the network connection. When the configuration settings are changed, you must restart the network connection. You can restart the network connection from Network Restart on the main menu. (📖*66*)
• If you connect the projector to an existing network, consult a network administrator before setting server addresses.
• The WEP Key, WPA passphrase and SSID settings will not be set if the invalid characters are used.
• The projector does not allow both wireless and wired LAN to be connected to the same network. Do not set the same network address for both wireless and wired LAN.

3.1 Projector Web Control (continued)

3.1.4 Port Settings



Displays and configures communication port settings.

Item		Description
Network Control Port1 (Port:23)		Configures command control port 1 (Port:23).
	Port open	Click the **[Enable]** check box to use port 23.
	Authentication	Click the **[Enable]** check box when authentication is required for this port.
Network Control Port2 (Port:9715)		Configures command control port 2 (Port:9715).
	Port open	Click the **[Enable]** check box to use port 9715.
	Authentication	Click the **[Enable]** check box when authentication is required for this port.
PJLink ™ Port (Port:4352)		Configures the PJLink ™ port (Port:4352).
	Port open	Click the **[Enable]** check box to use port 4352.
	Authentication	Click the **[Enable]** check box when authentication is required for this port.
My Image Port (Port:9716)		Configures the My Image Port (Port:9716).
	Port open	Click the **[Enable]** check box to use port 9716.
	Authentication	Click the **[Enable]** check box when authentication is required for this port.
Messenger Port (Port:9719)		Configures the Messenger Port (Port:9719).
	Port open	Click the **[Enable]** check box to use port 9719.
	Authentication	Click the **[Enable]** check box when authentication is required for this port.

(continued on next page)

3.1 Projector Web Control - Port Settings (continued)


Item		Description
SNMP Port		Configures the mib file port.
	Port open	Click the **[Enable]** check box to use SNMP.
	Trap address	Configures the destination of the SNMP Trap in IP format. • The address allows not only IP address but also domain name if the valid DNS server is setup in the **Network Settings**. The maximum length of host or domain name is up to 255 characters.
	Download MIB file	Downloads a MIB file from the projector.
Network Bridge Port		Configures the Bridge port number.
	Port number	Input the port number. Except for 41794, 9715, 9716, 9719, 9720, 5900, 5500, 4352 between 1024 and 65535 can be set up. It is set to 9717 as the default setting.

Click the **[Apply]** button to save the settings.

NOTE • The new configuration settings are activated after restarting the network connection. When the configuration settings are changed, you must restart the network connection. You can restart the network connection from Network Restart on the main menu. (🕮66)

3.1 Projector Web Control (continued)

3.1.5 Mail Settings



Displays and configures e-mail addressing settings.

Item		Description
Send Mail		Click the **[Enable]** check box to use the e-mail function. Configure the conditions for sending e-mail under the **Alert Settings**.
Authentication		Selects the authenticaton method. Enter the user name of the SMTP server or POP server as the user name. Enter the password of the SMTP server or POP server as the password. The maximum number of input characters is 63. Only alphabets, numbers and the following symbols can be used. !"#$%&'()*+,-./:;<=>?@[\]^_`{|}~ and space.
SMTP Server		Configures the SMTP server.
	Server address	Configures the SMTP server address. • The address allows not only IP address but also domain name if the valid DNS server is setup in the **Network Settings**. The maximum length of host or domain name is up to 255 characters. Alphanumeric characters, "-", or "." can be used.
	Port number	Configures the port number of the SMTP server. It is set to 25 as the default setting.
POP Server		Configures the POP server.
	Server address	Configures the POP server address. • The address allows not only IP address but also domain name if the valid DNS server is setup in the **Network Settings**. The maximum length of host or domain name is up to 255 characters. Alphanumeric characters, "-", or "." can be used.
	Port number	Configures the port number of the POP server. It is set to 110 as the default setting.

(continued on next page)

3.1 Projector Web Control - Mail Settings (continued)

Item	Description
Sender E-mail address	Configures the sender e-mail address. The length of the sender e-mail address can be up to 255 alphanumeric characters.
Recipient E-mail address	Configures the e-mail address of up to five recipients. You can also specify the **[to]** or **[cc]** for each address. The length of the recipient e-mail address can be up to 255 alphanumeric characters.
Send Test Mail	Sends a test e-mail to the set address.


Click the **[Apply]** button to save the settings.

Mail settings are initialized when clicking the **[Reset]** button.

NOTE • You can confirm whether the mail settings work correctly by using the **[Send Test Mail]** button. Enable Send Mail setting before clicking the **[Send Test Mail]**.
• If you connect the projector to an existing network, consult a network administrator before setting server addresses.

3.1 Projector Web Control (continued)

3.1.6 Alert Settings



Displays and configures failure & alert settings.

Notification such as e-mail and SNMP trap can be set regarding the following errors/warnings.

- ·Cover Error
- ·Fan Error
- ·Lamp Error
- ·Temp Error
- ·Air Flow Error
- ·Cold Error
- ·Filter Error
- ·Shade Error
- ·Lens Shift Error
- ·AC Blackout Error
- ·Other Error
- ·Schedule Execution Error
- ·Lamp Time Alarm
- ·Filter Time Alarm
- ·Filter Status Notification
- ·Transition Detector Alarm
- ·Cold Start
- ·Authentication Failure

Refer to Chapter 8-1 for the details of the above errors/warnings. (📖*89*)

3.1 Projector Web Control - Alert Settings (continued)


The Alert Items are shown below.

Item	Description
Alarm Time	Configures the time to alert. (Only **Lamp Time Alarm** and **Filter Time Alarm**.)
SNMP Trap	Click the **[Enable]** check box to enable SNMP Trap alerts.
Send Mail	Click the **[Enable]** check box to enable e-mail alerts. (Except **Cold Start** and **Authentication Failure**.)
Mail Subject	Configures the subject line of the e-mail to be sent. The length of the subject line can be up to 100 alphanumeric characters. Using any other character may shorten the subject line. (Except **Cold Start** and **Authentication Failure**.)
Mail Text	Configures the text of the e-mail to be sent. The length of the text is up to 1024 alphanumeric characters. Using any other character may shorten the text. (Except **Cold Start** and **Authentication Failure**.)

Click the **[Apply]** button to save the settings.
The settings are initialized when clicking the **[Reset]** button.

3.1 Projector Web Control (continued)

3.1.7 Schedule Settings



Displays and configures schedule settings.

NOTE • Be sure to set the date and time before enabling scheduled events. (📖56)
• Refer to 8.3 Event Scheduling for the details of schedule settings. (📖94)

1) Schedule Management

Item	Description
Sunday	Schedule settings executed on each day of the week.
Monday	
Tuesday	
Wednesday	
Thursday	
Friday	
Saturday	
Specific date No.1	Schedule settings executed on specified day. Up to 10 days can be specified.
Specific date No.2	
Specific date No.3	
Specific date No.4	
Specific date No.5	
Specific date No.6	
Specific date No.7	
Specific date No.8	
Specific date No.9	
Specific date No.10	


3.1 Projector Web Control - Schedule Settings (continued)

Item	Description
Schedule	Select the checkbox of the schedule to execute.
Program	Select the program. The detail of the event registered in each program can be confirmed in the program list displayed at the bottom of the screen.
Date (Month/Day)	Input the date (month/day) when the schedule is executed for Specific date 1~10.

Click the **[Apply]** button to save the settings.
Click the **[Refresh]** button to update the screen to the latest status.
Click the **[Program Edit]** button to display the program edit of the selected program.
Click the **[Copy to]** button to copy the content of the program from which you copy (the list on the left) to the program to which you copy (the list on the right). The same program No. cannot be selected for both the program from which and the program to which you copy.

3.1 Projector Web Control - Schedule Settings (continued)

2) Program Edit



The current event settings are displayed on the list. To add additional functions and events, set the following items.

NOTE • A maximum of 16 programs of schedule can be set. A maximum of 20 events can be registered in 1 program.

Item			Description
Time			Configures the time to execute events.
Event [Parameter]			Configures the events to be executed.
	Power		Configures the parameters for power control.
		STANDBY	
		ON	
	Input Source		Configures the parameters for switching input.
		COMPUTER IN	
		HDMI 1	
		HDMI 2	
		DisplayPort	
		HDBaseT	
		SDI (CP-WU8700 only)	
		VIDEO	
		LAN	
	My Image		Configures the parameters for My Image data display.
		IMAGE-OFF	
		IMAGE-1	
		IMAGE-2	
		IMAGE-3	
		IMAGE-4	


3.1 Projector Web Control - Schedule Settings (continued)

Item		Description
Messenger		Configures the parameters for Messenger data display.
	TEXT-OFF	
	TEXT-1	
	TEXT-2	
	TEXT-3	
	TEXT-4	
	TEXT-5	
	TEXT-6	
	TEXT-7	
	TEXT-8	
	TEXT-9	
	TEXT-10	
	TEXT-11	
	TEXT-12	
Eco Mode		Configures the parameters for eco mode switching.
	NORMAL	
	ECO	
Blank		Configures the parameters for blank screen on/off control.
	OFF	
	ON	

Click the **[Register]** button to add new events to the program.
Click the **[Delete]** button to delete events from the program.
Click the **[Delete All]** button to clear all the events registered in the current selected program.
Click the **[Back]** button to go back to the schedule management screen.

3.1 Projector Web Control (continued)

3.1.8 Date/Time Settings



Displays and configures the date and time settings.

Item			Description
Current Date			Configures the current date in **year/month/day** format.
Current Time			Configures the current time in **hour:minute:second** format.
Daylight Savings Time			Click the **[ON]** check box to enable daylight savings time and set the following items.
	Start		Configures the date and time daylight savings time begins.
		Month	Configures the month daylight savings time begins (1~12).
		Week	Configures the week of the month daylight savings time begins (First, 2, 3, 4, Last).
		Day	Configures the day of the week daylight savings time begins (Sun, Mon, Tue, Wed, Thu, Fri, Sat).
		Time **hour**	Configures the hour daylight savings time begins (0 ~ 23).
		Time **minute**	Configures the minute daylight savings time begins (0 ~ 59).
	End		Configures the date and time daylight savings time ends.
		Month	Configures the month daylight savings time ends (1 ~ 12).
		Week	Configures the week of the month daylight savings time ends (First, 2, 3, 4, Last).
		Day	Configures the day of the week daylight savings time ends (Sun, Mon, Tue, Wed, Thu, Fri, Sat).
		Time **hour**	Configures the hour daylight savings time ends (0 ~ 23).
		Time **minute**	Configures the minute daylight savings time ends (0 ~ 59).

(continued on next page)

3.1 Projector Web Control - Date/Time Settings (continued)


Item		Description
Time difference		Configures the time difference. Set the same time difference as the one set on your computer. If unsure, consult your IT manager.
SNTP	**SNTP Server Address**	Configures the SNTP server address in IP format. • The address allows not only IP address but also domain name if the valid DNS server is setup in the Network Settings. The maximum length of host or domain name is up to 255 characters.
	Cycle	Configures the interval at which to retrieve Date and Time information from the SNTP server (**hour:minute**).

Click the **[Apply]** button to save the settings.

NOTE • The new configuration settings are activated after restarting the network connection. When the configuration settings are changed, you must restart the network connection. You can restart the network connection from Network Restart on the main menu. (🕮*66*)
• If you connect the projector to an existing network, consult a network administrator before setting server addresses.
• To enable the SNTP function, the time difference must be set.
• The projector will retrieve Date and Time information from the time server and override time settings when SNTP is enabled.
• The internal clock's time may not remain accurate. Using SNTP is recommended to maintain accurate time.
• The internal battery is required to be replaced when the time is off soon after setting date and time.

3.1 Projector Web Control (continued)

3.1.9 Security Settings



Displays and configures passwords and other security settings.

Item		Description
User Account		Configures the user name and password.
	User name	Configures the user name. The length of the text can be up to 32 alphanumeric characters.
	Password	Configures the password. The length of the text can be up to 255 alphanumeric characters.
	Re-enter Password	Reenter the above password for verification.
Network Control		Configures the Authentication password for Network Control Port1 (Port: 23), Network Control Port2 (Port: 9715), PJLink™ Port (Port: 4352), My Image Port (Port: 9716), and Messenger Port (Port: 9719). (📖46)
	Authentication Password	Configures the Authentication password. The length of the text can be up to 32 alphanumeric characters.
	Re-enter Authentication Password	Reenter the above password for verification.
Network Presentation		Setting an authentication password used in Network Presentation.The authentication function is disabled when an authentication password is not set.
	Authentication Password	Configures the Authentication password. The length of the text can be up to 15 alphanumeric characters.
	Re-enter Authentication Password	Reenter the above password for verification.

(continued on next page)

3.1 Projector Web Control - Security Settings (continued)


Item		Description
SNMP		Configures the community name if SNMP is used.
	Community name	Configures the community name. The length of the text can be up to 64 alphanumeric characters.

Click the **[Apply]** button to save the settings.

NOTE • The new configuration settings are activated after restarting the network connection. When the configuration settings are changed, you must restart the network connection. You can restart the network connection from Network Restart on the main menu. (📖*66*)
• Only numbers '0-9', alphabet 'a-z' and 'A-Z' can be used.

3.1 Projector Web Control (continued)

3.1.10 Projector Control



Operations of the projector can be performed with the items on the screen.
The categories of the items are shown in the main menu. Most of the items have a submenu. Refer to the table below for details.

NOTE • The setting value may not match with the actual value if the user changes the value manually. In that case, refresh the page by clicking the **[Refresh]** button.

Item	
MAIN	**POWER**
	INPUT SOURCE
	BLANK ON/OFF
	MUTE
	FREEZE
	MAGNIFY
	MAGNIFY POSITION V
	MAGNIFY POSITION H
	TEMPLATE
	SHADE [ON]: closed / [OFF]: opened
	ZOOM ⏮ / ⏭: Turns the lens to the upper or lower limit of its movable range. ■: Stops turning the lens. « / ‹ / › / »: Fine adjustment in two steps is available.
	FOCUS ⏮ / ⏭: Turns the lens to the upper or lower limit of its movable range. ■: Stops turning the lens. « / ‹ / › / »: Fine adjustment in two steps is available.
	LENS SHIFT V **LENS SHIFT H** ⏮ / ⏭: Turns the lens to the upper or lower limit of its movable range. ■: Stops turning the lens. « / ‹ / › / »: Vertical and horizontal fine adjustment in two steps is available.

(continued on next page)

3.1 Projector Web Control - Projector Control (continued)

Item		
MAIN (continued)	**LENS MEMORY**	
	WINDOW CONFIGURATION - OFF / PbyP / PinP Click the [Apply] button to execute after selecting the display mode (OFF/ PbyP/ PinP) from the dropdown list. Click the [Edit] button to display the screen for detailed settings while PbyP or PinP display mode.	
	MY IMAGE	
	MY IMAGE DELETE	
PICTURE	**PICTURE QUALITY**	**PICTURE MODE**
		GAMMA
		COLOR TEMP
		ACCENTUALIZER
		HDCR
		COLOR MANAGEMENT
	BRIGHTNESS	
	CONTRAST	
	COLOR	
	TINT	
	SHARPNESS	
	ACTIVE IRIS	
	MY MEMORY	
IMAGE	**ASPECT** The selected parameter cannot be set depending on the input signal.	
	OVER SCAN	
	V POSITION	
	H POSITION	
	H PHASE	
	H SIZE	
	AUTO ADJUST EXECUTE	
INPUT	**PROGRESSIVE**	
	VIDEO NR	
	COLOR SPACE	
	VIDEO FORMAT	
	DIGITAL FORMAT	
	DIGITAL RANGE	
	COMPUTER IN	
	FRAME LOCK	

(continued on next page)

3.1 Projector Web Control - Projector Control (continued)

Item		
SETUP	KEYSTONE	KEYSTONE V
		KEYSTONE H
	PERFECT FIT	SETUP - Corner Position/Line Distortion
	WARPING	MODE
	EDGE BLENDING	MODE
		BLENDING LEVEL
		BLENDING REGION
		CROPPING
		DIMMING LEVEL
		WHITE BALANCE GAIN
		WHITE BALANCE OFFSET
		BLACK LEVEL
	LAMP & FILTER	ECO MODE
		FILTER MESSAGE
	IMAGE OPTIMIZER	
	PICTURE POSITION	
	INSTALLATION	
	STANDBY MODE **NOTE** • The network function is not available when STANDBY MODE is set to SAVING and the projector is in standby mode. Connect the projector to the network after setting STANDBY MODE to NORMAL.	
	OSD MESSAGE	
AUDIO	VOLUME	
	SPEAKER	
	AUDIO SOURCE	


(continued on next page)

3.1 Projector Web Control - Projector Control (continued)


Item	
SCREEN	**LANGUAGE** Click the **[Apply]** button to switch the language on the Web screen according to the setting of the selected language in the projector.
	MENU POSITION V **MENU POSITION H**
	BLANK
	AUTO BLANK
	START UP
	MyScreen Lock
	TEMPLATE
	C.C. - DISPLAY
	C.C. - MODE
	C.C. - CHANNEL
OPTION	**SOURCE SKIP**
	AUTO SEARCH
	DIRECT POWER ON
	AUTO POWER OFF
	SHADE TIMER
	MY BUTTON – 1 / 2 / 3 / 4
	REMOTE RECEIV.
	REMOTE FREQ.
	REMOTE ID
SERVICE	**Quit Presenter Mode** Quit compulsorily from the Presenter mode. Refer to Chapter 4 for the details of Presenter Mode. (🕮77)

3.1 Projector Web Control (continued)

3.1.11 Remote Control



CP-WU8600/CP-WX8650
CP-WX8750/CP-X8800



CP-WU8700

The functions on the bundled remote control are assigned to the Web Remote Control screen.


Do not control the projector with the projector's remote control and via Web Remote Control at the same time. It may cause some operational errors in the projector.

- **STANDBY**
- **ON**
- **COMPUTER IN**
- **HDMI 1**
- **HDMI 2**
- **DisplayPort**
- **HDBaseT**
- **SDI (CP-WU8700 only)**
- **VIDEO**
- **LAN**
- **AV MUTE**
- **FREEZE**
- **▲/ ▼/ ◄ / ►**
- **ENTER**
- **MENU**
- **RESET**

NOTE • One operation can be executed only with one click. The button should be clicked repeatedly to operate continuously.
• When clicking the button repeatedly, some commands may not be sent correctly. Click it at intervals.
• When the **[STANDBY]** or **[ON]** button is pushed, a message window comes up to confirm the operation. To control the power, push **[OK]**, otherwise push **[Cancel]**.

3.1 Projector Web Control (continued)

3.1.12 Projector Status




Displays the current settings and status of the projector.

Item	Description
Error Status	Displays the error status.
Lamp Time	Displays the usage time for the lamp.
Filter Time	Displays the usage time for the filter.
Filter Status	Displays the current cleanliness level of the air filter.
Power Status	Displays the power status.
Input Status	Displays the input signal source.
Blank On/Off	Displays the Blank screen on/off status.
Mute	Displays the Mute on/off status.
Freeze	Displays the Freeze status.
Shade	Displays the Shade status.

3.1 Projector Web Control (continued)

3.1.13 Network Restart




Restarts the projector's network connection.

Item	Description
Restart	Restarts the projector's network connection in order to activate new configuration settings.

NOTE • Restarting requires you to re-login in order to further control or configure the projector via a web browser. Wait 30 seconds or more after clicking the **[Restart]** button to log on again.

3.1 Projector Web Control (continued)

3.1.14 Connection Test



Checks if the network is connecting to DNS server or SNTP server, etc.

Item	Description
Destination IP Address	Click the **[Execute]** button to test the connection after entering IP address to connect to.

Display example of the connection succeeded :

```
PING 192.168.1.200 (192.168.1.200): 56 data bytes
64 bytes from 192.168.1.200: seq=0 ttl=128 time=2.136 ms
64 bytes from 192.168.1.200: seq=1 ttl=128 time=0.524 ms

--- 192.168.1.200 ping statistics ---
2 packets transmitted, 2 packets received, 0% packet loss
round-trip min/avg/max = 0.524/1.330/2.136 ms
```

Display example of the connection failed :

```
PING 192.168.100.200 (192.168.100.200): 56 data bytes


Destination host unreachable.
```

NOTE • Confirm information of the target IP address with network administrator.
• Connection test may result in an error even if the connection is performed properly when the packets for checking the connection are discarded before arriving at the target depending on the settings of firewall or packet filtering, etc.
• The result of the connection test is displayed only in English.

3.2 Crestron e-Control®



The Main window as shown above is displayed at first. However, if you have enabled User Password on the Tools window (72), a dialog prompting you to enter the password as shown on the right will be displayed, and no operation is enabled until you have entered the password. After entering the preset password, the dialog disappears and the Main window will be displayed.
As shown below, you can open a window by clicking the corresponding tab at the top right of the window.



User Password dialog

Tab	Description
Logout	Logs out from e-Control®. This tab appears only when User Password of the Tools window is enabled.
Tools	Opens Tools window. (72)
Info	Opens Info window. (74)
Contact IT Help	Opens Help Desk window. (75)


3.2 Crestron e-Control® (continued)

NOTE • In any of the following cases, the selection window does not appear but the Login window of the Projector Web Control is displayed.
- Network Settings - Other Setup - Crestron e-Control is "Disable" (45)
- Network Settings - Common Setup - Crestron is "OFF" (42)
- NETWORK menu - EXTERNAL CONTROL - CRESTRON is "OFF" (34)

Set Crestron to on and enable Crestron e-Control, then close the web browser. Next, restart the web browser, followed by entering the projector's IP address.
• Only English is supported on Crestron e-Control®.
• If the connection is terminated, the "Loading..." screen will appear. Check the connection between the projector and the computer, then return or refresh the Web page.
• The control from Crestron e-Control® is supported only via wired LAN.

3.2 Crestron e-Control® (continued)

3.2.1 Main window



You can operate the basic controls of the projector on this screen.

NOTE • If the projector is in the standby mode, only the **[Power]** button can be operated.

1. Click a button and operate as follows.

Button	Description
Power	Turns the power on/off.
Vol - / Vol +	Adjusts the volume setting.
Mute	Turns Mute on/off.

2. **Sources List**
You can click a button to switch the input channel. The cursor will move according to the currently selected input port.

Button	Description
Computer In	Selects input from **COMPUTER IN** port.
HDMI 1	Selects input from **HDMI 1** port.
HDMI 2	Selects input from **HDMI 2** port.
DisplayPort	Selects input from **DisplayPort** port.
HDBaseT	Selects input from **HDBaseT™** port.
SDI (CP-WU8700 only)	Selects input from **SDI** port.
Video	Selects input from **VIDEO** port.
LAN	Selects input from **LAN** port.

3.2 Crestron e-Control® - Main window (continued)

3. Click a button and operate as follows. To show the hidden buttons, click the ◄ / ► icons at the left and right ends.


Button	Description
Freeze	Turns Freeze on/off.
Contrast	Adjusts the contrast setting.
Brightness	Adjusts the brightness setting.
Color	Adjusts the color setting.
Sharpness	Adjusts the sharpness setting.
Magnify	Controls the magnification setting using the [+] / [-] buttons. Use the [▲] [▼] [◄] [►] buttons to move to the area you want to magnify.
Auto	Performs the automatic adjustment.
Blank	Turns the BLANK screen on/off.

4. Click the button and operate in the same way as the bundled remote control.

Button	Description
Menu	Assigned the same operation as **MENU** button.
Enter	Assigned the same operation as **ENTER** button.
Reset	Assigned the same operation as **RESET** button.
▲	Assigned the same operation as ▲ button.
▼	Assigned the same operation as ▼ button.
◄	Assigned the same operation as ◄ button.
►	Assigned the same operation as ► button.

3.2 Crestron e-Control® (continued)

3.2.2 Tools window



Configures the settings between the projector and Crestron® control system. Click the **[Exit]** button to return to the Main window.

NOTE • If two-byte characters are used, the input text or numbers cannot be set correctly.
• Any items on this window cannot be left blank.

1. **Crestron Control**
Configures the settings of Crestron® control system devices.

Item	Description
IP Address	Configures the IP address of the control system.
IP ID	Configures the IP ID of the control system.
Port	Specifies the port number used for communication by the control system.

To apply the settings, click the **[Send]** button.

2. **Projector**
Configures the network settings of the projector.

Item	Description
Projector Name	Configures the name of the projector. The length of the Projector Name can be up to 64 alphanumeric characters.
Location	Configures the location name of the projector. You can specify a Location name up to 32 alphanumeric characters.
Assigned To:	Configures the user name for the projector. You can specify a user name up to 32 alphanumeric characters.

The usable symbols are space and the following:
!"#$%&'()*+,-./:;<=>?@[\]^_`{|}~
To apply the settings, click the **[Send]** button.

3.2 Crestron e-Control® - Tools window (continued)

3. **Projector** (continued)
Configures the network settings of the projector.

Item	Description
DHCP	Enables DHCP.
IP Address	Configures the IP address when DHCP is disabled.
Subnet Mask	Configures the subnet mask when DHCP is disabled.
Default Gateway	Configures the default gateway when DHCP is disabled.
DNS Server	Configures the DNS server address when DHCP is disabled.

To apply the settings, click the **[Send]** button.

4. **User Password**
Configures the User Password. To prompt the entry of User Password before starting e-Control®, select the checkbox.

Item	Description
New Password	Configures the password. You can specify a password up to 26 alphanumeric characters. The usable symbols are space and the following: !"#$%&'()*+,-./:;<=>?@[\]^_`{|}~
Confirm	Reenter the above password for verification. If the password is incorrect, an error message is displayed.

To apply the settings, click the **[Send]** button.


5. **Admin Password**
Configures the Admin Password. To prompt the entry of Admin Password before displaying the Tools window, select the checkbox.

Item	Description
New Password	Configures the password. You can specify a password up to 26 alphanumeric characters. The usable symbols are space and the following: !"#$%&'()*+,-./:;<=>?@[\]^_`{|}~
Confirm	Reenter the above password for verification. If the password is incorrect, an error message is displayed.

To apply the settings, click the **[Send]** button.

3.2 Crestron e-Control® (continued)

3.2.3 Info window



Displays the current settings and status of the projector.
Click the **[Exit]** button to return to the Main window.

1. **Projector Information**

Item	Description
Projector Name	Displays the projector name settings.
Location	Displays the location name of the projector.
MAC Address	Displays the wired LAN MAC address of the projector.
Resolution	Displays the resolution and vertical frequency of the signal input selected on the projector.
Lamp Hours	Displays the usage time for the lamp.
Assigned To:	Displays the user name for the projector.


2. **Projector Status**

Item	Description
Power Status	Displays the power status.
Input Source	Displays the input signal source.
Picture Mode	Displays the picture mode setting.
Installation	Displays the installation setting.
Eco Mode	Displays the eco mode setting.
Error Status	Displays the error status.

NOTE • Projector Name, Location and the user name for Assigned To: may appear truncated if they are too long.

3.2 Crestron e-Control® (continued)

3.2.4 Help Desk window



Sends/receives messages to/from the administrator for Crestron RoomView® Express and Fusion RV®.

Button	Description
Send	Sends a message.
	Checks the received message.

3.2 Crestron e-Control® (continued)

3.2.5 Emergency Alert



When the administrator for Crestron RoomView® Express and Fusion RV® sends out an alert message, it will be displayed on the screen.
You can reply to the alert message via a chat format. Input a message in the box below the alert message, and click the **[Send]** button.

NOTE • For details of Emergency Alert, refer to the manual of Crestron RoomView® Express or Fusion RV®.
• The alert message from Crestron RoomView® and Fusion RV® is displayed on the screen of the projector in the way similar to the real-time text of the Messenger function. (📖*82*) If another real-time text is displayed on the screen, it will be overwritten by the alert message. However, if the priority of the real-time text is set to high, the alert message does not appear on the screen. For details, refer to the manual for the application of the Messenger.

4. Network Presentation

4.1 Outline

The projector can display or play back the computer screen images and audio data that are transmitted through the network. This Network Presentation feature helps you to smoothly make your presentations and conduct conferences.



To use Network Presentation, an exclusive application, "LiveViewer" is required. It can be installed from the bundled application CD.

For details of Network Presentation and instructions to install the "LiveViewer", refer to the manual for "LiveViewer".

NOTE • The use of "LiveViewer" function depends on the model you are using. If you want to use the latest "LiveViewer", please refer to the appropriate group item in the "LiveViewer" User's Manual. This model will be in the Group of H.
• For Mac user, download the software from the website. Refer to 2.5. Applications.

4.2 Display Mode

LiveViewer has two display modes, Single PC mode and Multi PC mode.

4.2.1 Single PC mode

The Single PC mode can display images in full screen from one computer to the projector/switcher via wireless LAN or wired LAN.

■ Presenter Mode
In the Single PC mode, the projector can be occupied by one computer and can block access from any other computers (if Presenter Mode is set to ON in LiveViewer). While making your presentation, you don't need to worry that the image on screen will be unexpectedly switched to an image sent by another computer. Presenter Mode can be set to ON in the option menu in the LiveViewer.


4.2.2 Multi PC mode

The projector can display images of up to four computers connected at the same time.



4.3 Multi Projector Mode


In the Multi Projector/Multi Display mode, up to 12 projectors or switchers connected to projectors can connect with the computer via wireless or wired LAN simultaneously.



This function is for Windows users only.

4.4 Moderator Control Mode

One computer can be assigned as Moderator (Host) to control all other computers (Clients) or the switchers connected with the projector via wireless LAN or wired LAN. Since Clients cannot control the LiveViewer and the projector, the Host can proceed with the program as arranged smoothly and safely.



This function is for Windows users only.

4.5 Port Number

The port numbers used for LiveViewer are shown below.


Port No.	Protocol
5500	TCP
5900	TCP
9720	TCP

NOTE

• When other application uses the ports above, LiveViewer and Projector Quick Connection may not work.

5. My Image Function

The projector can display still images transferred via the network.
It is possible to allocate up to 4 image files.



MY IMAGE transmission requires an exclusive application for your computer.
Use the application to transfer the image data.


For information on the necessary settings and operations for the computer and projector, refer to the manual for the application.
To display the transferred image, select the MY IMAGE item in the NETWORK menu. For more information, please see the description of the MY IMAGE item of the NETWORK menu.

NOTE • Using MY BUTTON registered as MY IMAGE can display transferred image. (📖OPTION menu in the Operating Guide)
• The image file also can be displayed by using schedule function from the web browser.(📖*94*)
• If data is transferred via wireless and wired LAN at the same time, the projector may not be able to process the data correctly.


6. Messenger Function

6.1 Outline


The projector can display text data transferred via the network on the screen and play back audio data inside the projector.
The text data can be displayed on the screen in two ways. One is to display the text transferred from the computer on real time, and the other is to choose the text data stored in the projector and display it.
It is possible to store up to 12 text data.



Transfer text data



Display text data (ex. 4)



Messenger function requires an exclusive application for your computer. To edit, transfer and display the text data, use the application.

For information on the necessary settings and operations for the computer and projector, refer to the manual for the application.

6.2 Supported Languages


The languages that can be displayed by Messenger function are shown below.

English, French, German, Spanish, Italian, Norwegian, Dutch, Portuguese, Swedish, Finnish, Danish, Brasileiro, Indonesian, Lithuanian, Estonian, Latvian, Polish, Czech, Hungarian, Slovenian, Croatian, Russian, Turkish, Greek, Japanese, Simplified Chinese, Traditional Chinese, Korean, Vietnamese


6.3 Display Style

There are 4 types of message display style. The following is the description of each type.


1) Scroll
The message scrolls to the left in the message display area.



2) Box (Scroll up)
The message scrolls upwards in the square message display area.



3) Pop on
The message is displayed in full view in the square message display area.




4) Picture Side
The message is displayed in the message display area on the right or left.
This style is available only for WXGA and WUXGA model projector.



NOTE • Using **MY BUTTON** registered as MESSENGER can turn the displaying messenger text on/off. (📖OPTION menu in the Operating Guide)
• The text file also can be displayed by using schedule function via the web browser. (📖*94*)
• If data is transferred via wireless and wired LAN at the same time, the projector may not process the data correctly.

7. Network Bridge Function

This projector is equipped with the NETWORK BRIDGE function to perform mutual conversion of a network protocol and a serial interface.
By making use of the NETWORK BRIDGE function, a computer connected to the projector via wireless or wired LAN is able to control an external device via RS-232C communication using the projector as a network terminal.



7.1 Connecting devices

1) Connect the projector's **LAN** port to the computer's LAN port with a LAN cable, or insert the USB wireless adapter into the **WIRELESS** port.
2) Connect the projector's **CONTROL** port and the device's RS-232C port with an RS-232C cable, for RS-232C communication.

NOTE • Before connecting the devices, read the manuals for the devices to ensure the connection. For RS-232C connection, check the specifications of each port and use the suitable cable. (📖Connection to the ports in the Operating Guide - Technical)

7.2 Communication setup

To configure the setup of the communication using NETWORK BRIDGE for the projector, use items in the COMMUNICATION menu. Open the menu of the projector and select the OPTION - SERVICE - COMMUNICATION menu. (📖OPTION menu > SERVICE > COMMUNICATION in the Operating Guide)

1) In the COMMUNICATION TYPE menu, select NETWORK BRIDGE (WIRELESS or WIRED depending on the type of connection you use) for the **CONTROL** port.
2) Using the SERIAL SETTINGS menu, select the proper baud rate and parity for the **CONTROL** port, according to the specification of the RS-232C port of the connected device.

Item	Condition
BAUD RATE	4800bps/9600bps/19200bps/38400bps
PARITY	NONE/ODD/EVEN
Data length	8 bit (fixed)
Start bit	1 bit (fixed)
Stop bit	1 bit (fixed)

3) Using the TRANSMISSION METHOD menu, set up the proper method for the **CONTROL** port according to your use.

NOTE • The OFF is selected for the COMMUNICATION TYPE as the default setting.
• Using the COMMUNICATION menu, set up the communication. Remember that an unsuitable setup could cause malfunction of communication.
• When either one of the NETWORK BRIDGE settings is selected in the COMMUNICATION TYPE menu, RS-232C commands cannot be received from the **CONTROL** port.

7.3 Communication port

For the NETWORK BRIDGE function, send the data from the computer to the projector with using the Network Bridge Port configured in the Port Settings of web browser. (📖*46*)

NOTE • Except for 41794, 9715, 9716, 9719, 9720, 5900, 5500, 4352 between 1024 and 65535 can be set up as the Network Bridge Port number. It is set to 9717 as the default setting.

7.4 Transmission method


The transmission method can be selected from the menus, only when the NETWORK BRIDGE is selected for the COMMUNICATION TYPE.
(📖OPTION menu > SERVICE > COMMUNICATION in the Operating Guide)

HALF-DUPLEX ↔ FULL-DUPLEX

7.4.1 HALF-DUPLEX

This method lets the projector make two way communication, but only one direction, either transmitting or receiving data, is allowed at a time.
The method does not allow the projector to receive the data from the computer while waiting for response data from an external device. After the projector receives the response data from an external device or the response limit time is past, the projector can receive the data from the computer.
That means that the projector controls transmitting and receiving the data to synchronize the communication.

To use the HALF-DUPLEX method, set up the RESPONSE LIMIT TIME following the instructions below.



Using the RESPONSE LIMIT TIME menu, set the waiting time for response data from an external device. (📖OPTION menu > SERVICE > COMMUNICATION in the Operating Guide)

OFF ↔ 1s ↔ 2s ↔ 3s (↔ OFF)

7.4 Transmission method (continued)

NOTE • With using the HALF-DUPLEX method, the projector can send out 254 byte data at the maximum at a time.
• If it is not required to monitor the response data from an external device and the RESPONSE LIMIT TIME is set to OFF, the projector can receive the data from the computer and send it out to an external device continuously.
The OFF is selected as the default setting.

7.4.2 FULL-DUPLEX

This method lets the projector make two way communication, transmitting and receiving data at the same time, without monitoring response data from an external device.
With using this method, the computer and an external device will send the data out of synchronization. If it is required to synchronize them, set the computer to make the synchronization.

NOTE
• When the computer controls the synchronization of receptions and transmissions, the external device may not be controlled properly depending on the status of data processing of the projector.

8. Other Functions

8.1 E-mail Alerts

The projector can automatically send an alert message to the specified e-mail addresses when the projector detects a certain condition that is requiring maintenance or detected an error.

NOTE • Up to five e-mail addresses can be specified.
• The projector may be not able to send e-mail if the projector suddenly loses power.
• Mails may not be sent correctly depending on the mail environment you are using.

Alerts available to E-mail alerts are as follows.

Item	Description
Cover Error	The lamp cover has not been properly fixed.
Fan Error	The cooling fan is not operating.
Lamp Error	The lamp does not light, and there is a possibility that interior portion has become heated.
Temp Error	There is a possibility that the interior portion has become heated.
Air Flow Error	The internal temperature is rising.
Cold Error	There is a possibility that the interior portion has become overcooled.
Filter Error	Filter time over.
Shade Error	The shutter does not work correctly.
Lens Shift Error	The Lens shift does not work correctly.
AC Blackout Error	Power supply was interrupted momentarily.
Other Error	Errors other than the above. If this error is displayed, please contact your dealer.
Schedule Execution Error	Failed to execute scheduled events.
Lamp Time Alarm	Lamp Time has exceeded the specified alarm limit.
Filter Time Alarm	Filter Time has exceeded the specified alarm limit.
Filter Status Notification	The status to clean the air filter is changed.
Transition Detector Alarm	Transition Detector Alarm. (📖**SECURITY menu** in the **Operating Guide**)

(continued on next page)

NOTE • The timing of receiving Filter Error e-mail is depending on the FILTER MESSAGE setting in the LAMP & FILTER item of the SETUP menu which determines the period until the filter message is displayed on the projector screen. An e-mail will be sent when the usage time of the filter exceeds the set time limit. No notification e-mail will be sent if the FILTER MESSAGE is set to OFF. (📖SETUP menu in the Operating Guide)
• **Lamp Time Alarm** is a threshold for e-mail notification of the lamp time. When the set time exceeds the limit configured in the Projector Web Control, an e-mail will be sent.
• **Filter Time Alarm** is a threshold for e-mail notification of the filter time. When the set time exceeds the limit configured in the Projector Web Control, an e-mail will be sent.
• **Filter Status Notification** can be enabled for both or either one of **Status 1** and **2**. These notifications are equivalent to the changing of the **FILTER** indicator on the projector. (**Status 1**: off to orange, **Status 2**: orange to red) Refer to the **Operating Guide** for details of the **FILTER** indicator.

To use the projector's e-mail alert function, please configure the following items through a web browser.

Mail Settings (📖*48*)

1) Select **[Mail Settings]** on main menu in Projector Web Control.
2) Configure each item in Mail Settings page. Refer to item 3.1.5 Mail Settings (📖*48*) for further information.
3) Click the **[Apply]** button to save the settings.
4) Click the **[Send Test Mail]** button to confirm that the e-mail settings are correct.

The following mail will be delivered to the specified addresses.

Subject line: Test Mail <Projector name>
Text : Send Test Mail

Date	<Testing date>
Time	<Testing time>
IP Address	<Projector IP address>
MAC Address	<Projector MAC address>

Alert Settings (📖*50*)

1) Select **[Alert Settings]** on main menu in Projector Web Control.
2) Select and configure each alert item. Refer to item 3.1.6 Alert Settings (📖*50*) for further information.
3) Click the **[Apply]** button to save the settings.

Failure/Warning e-mails are formatted as follows:

Subject line: <Mail title> <Projector name>
Text : <Mail text>

Date	<Failure/Warning date>
Time	<Failure/Warning time>
IP Address	<Projector IP address>
MAC Address	<Projector MAC address>

8.2 Projector Management using SNMP

The SNMP (Simple Network Management Protocol) enables to manage the projector information, which is a failure or warning status, from the computer on the network.

NOTE • It is recommended that SNMP functions are executed by a network administrator.
• SNMP management software must be installed on the computer to monitor the projector via SNMP.

Standard MIB (MIB-2)
You can refer the following items defined in system group of Standard MIB (MIB-2).

Item	Description
sysName	Projector name is set.
sysLocation	The information on where it is located. It has character string set in sysLocation (SNMP) in Projector Web Control - [Network Settings] - [Common Setup].
sysContact	The information on the administrator's contact information. It has character string set in sysContact (SNMP) in Projector Web Control - [Network Settings] - [Common Setup].

Enhanced MIB
You can get configuration information by using Enhanced MIB for projectors. Enhanced MIB for projectors can be downloaded from [Port Settings] page in Projector Web Control.

Trap
When an error or warning occurs in the projector, a notification can be sent to the specified address.
In addition to e-mail alert shown in 8.1 Email Alerts (📖*89*), the following notification can be sent.

Item	Description
Cold Start	When the projector is supplied with the power, it works as below. • If the STANDBY MODE is set to the NORMAL: the projector's power status changes from “OFF” to “Standby state”. • If the STANDBY MODE is set to the SAVING: the projector's power status changes from “Standby state” to “ON (lamp is turned on)”. (📖SETUP menu in the Operating Guide).
Authentication Failure	The SNMP access is detected from the invalid SNMP community.

Setup the following functions through WEB browser, if you want to manage the projector by SNMP.

Port Settings (📖*46*)
1) Select **[Port Settings]** on main menu in Projector Web Control.
2) Click the **[Download MIB file]** to download a MIB file.
3) Click the **[Enable**] check box to open the SNMP Port. Set the address to send the SNMP trap to when a Failure/Warning occurs.

Security Settings (📖*58*)
1) Select **[Security Settings]** on main menu in Projector Web Control.
2) Click the **[SNMP]** and set the community name on the screen that is displayed.

Alert Settings (📖*50*)
Configure the settings for Trap transmission of Failures/Warnings.
1) Select **[Alert Settings]** on main menu in Projector Web Control.
2) Select the Failure/Warning item to be configured.
3) Click the **[Enable]** check box to send out the SNMP trap for Failures/Warnings. Clear the **[Enable**] check box when SNMP trap transmission is not required.
4) Click the **[Apply]** button to save the settings.

NOTE • Register the downloaded MIB file to SNMP manager program to be used.
• Be sure to execute Network Restart when the settings of **[Port Settings]** or [**Security Settings]** is changed.

8.3 Event Scheduling

The scheduling function enables to setup scheduled events including power on / power off. It enables to be “self-management” projector.


Note the following before setting the schedule.

NOTE • Schedule can also be set in OPTION - SCHEDULE menu of the projector. (📖Refer to Operating Guide – OPTION).
• A maximum of 16 programs of schedule can be set. A maximum of 20 events can be registered in 1 program.
• No events are registered in program 1 – 16 with factory default settings. The program is required to be set in advance when using the schedule function for the first time.
• The priority for scheduled events is as follows 1) specific date 2) weekly
• Up to 10 specific dates are available for scheduled events. Priority is given to those with the lower numbers when more than one event has been scheduled for the same date and time (e.g., ‘Specific date No. 1’ has priority over ‘Specific date No. 2’ and so on.
• The power on event has the lowest priority among all the events that are set at the same time.
• Be sure to set the date and time before enabling scheduled events. (📖*56*)
• After the projector is moved, check the date and time set for the projector before configuring the schedules.
• The internal clock’s time may not remain accurate. Using SNTP is recommended to maintain accurate time.
• Certain error state in the projector (such as temperature error, lamp error) will prevent the projector from appropriate execution of scheduled functions/events.
• Events “**My Image**” and “**Messenger**” will not be executed appropriately and result in “schedule execution error” status when the lamp does not light and/or data to be displayed are not stored in the projector at the time when scheduled event is executed.
• Events “**Input Source**” and “**My Image**” is not executed if security function is enabled and the projector is locked due to the function.


The procedure to set the schedule in Projector Web Control is described in the following.

Setting the program is necessary to use the schedule function. Various events such as power on/off or switching input source, and the time to execute the events are to be registered in the program. No events are registered in program 1 – 16 with factory default settings. Set the program following the steps below.
In the case that the program has already been set, skip to step 6).

1) Select **[Schedule Settings]** on main menu in Projector Web Control.



2) Select the program number in dropdown list under Program List and click the **[Program Edit]** button to display the following program edit display. The display for editing Program-1 is shown below.



3) After setting the time, events and parameters, click the **[Register]** to add the new event.
Click the **[Delete]** button when you want to delete an event.
Click the **[Delete All]** button when you want to delete all the events in the currently selected program.

4) When you want to edit the program with other number continuously, select the program you want to edit in dropdown list and click the **[Select]** button to display the display for editing the selected program.

5) Click the **[Back]** button to go back to schedule management screen after finishing the program setting.

The procedure to assign the program set in the step 1) ~ 5) to the schedule is described in the following.


6) Click the checkbox of the schedule to be executed (e.g. Click the checkbox of “Monday”, when it is to be executed on Mondays) in the schedule management screen.

7) Select the program to be executed in dropdown list. You can confirm the event information registered in each program in the program list on the bottom of the screen.
When setting the Specific date No.1 ~ 10, enter the date (month/day).

8) Click the **[Apply]** button to save the schedule settings in the projector.
Repeat step 6) ~ 8) similarly to set the schedule you want to execute.

The schedule settings are now complete.
Finally, confirm the time stored in the projector is correctly set.

■How to copy the program
When you copy the currently selected program to other program, click the checkbox under  icon. Click the **[Copy to]** button after selecting the program to which you want to copy in dropdown list.
The same program as the currently selected one cannot be specified as the program to which you want to copy.



8.4 Command Control via the Network

You can configure and control the projector via the network using RS-232C commands.

Communication Port

The following two ports are assigned for the command control.


TCP #23 **(Network Control Port1 (Port: 23))**
TCP #9715 **(Network Control Port2 (Port: 9715))**

NOTE • Command control is available only via the specified port above.

Command Control Settings (📖46)

Configure the following items from a web browser when command control is used.

Example: If the IP address of the projector is set to **192.168.1.10:**
1) Enter "**http://192.168.1.10/**" into the address bar of the web browser, and select Projector Web Control from the selection window.
2) Enter your user name and password, and then click the **[OK]**.
3) Click the **[Port Settings]** on the main menu.



4) Click the **[Enable]** check box to open **Network Control Port1 (Port: 23)** to use TCP #23. Click the **[Enable]** check box for the **[Authentication]** setting when authentication is required, otherwise clear the check box.
5) Click the **[Enable]** check box to open **Network Control Port2 (Port: 9715)** to use TCP #9715. Click the **[Enable]** check box for the **[Authentication]** setting when authentication is required, otherwise clear the check box.
6) Click the **[Apply]** button to save the settings.

8.4 Command Control via the Network (continued)

When the authentication setting is enabled, the following settings are required. (📖*58*)

7) Click the **[Security Settings]** on the main menu.
8) Click the **[Network Control]** and enter the desired authentication password.
   * See NOTE.
9) Click the **[Apply]** button to save the settings.

NOTE • The Authentication Password will be the same for **Network Control Port1 (Port: 23)**, **Network Control Port2 (Port: 9715)**, **PJLink™ Port (Port: 4352)**, **My Image Port (Port: 9716)** and **Messenger Port (Port: 9719)**.
• The new configuration settings are activated after restarting the network connection. When the configuration settings are changed, you must restart the network connection. You can restart the network connection from Network Restart on the main menu. (📖*66*)

8.4 Command Control via the Network (continued)

Command Format

Command formats differ among the different communication ports.

● TCP #23

You can use the RS-232C commands without any changes. The reply data format is the same as the RS-232C commands. (📖RS-232C Communication in the Operating Guide - Technical)

However, the following reply will be sent back in the event of authentication failure when authentication is enabled.

<Reply in the event of an authentication error>

Reply	Error code	
0x1F	0x04	0x00

● TCP #9715

Send Data format

The following formatting is added to the header (0 x 02), Data length (0 x 0D), Checksum (1 byte) and Connection ID (1 byte) of the RS-232C commands.

Header	Data length	RS-232Ccommand	Check Sum	Connection ID
0x02	0x0D	13 bytes	1 byte	1 byte

Header → 0x02, Fixed
Data length → RS-232C commands byte length (0x0D, Fixed)
RS-232C command → RS-232C commands that start with 0xBE 0xEF (13 bytes)
Check Sum → This is the value to make zero on the addition of the lower 8 bits from the header to the checksum.
Connection ID → Random value from 0 to 255 (This value is attached to the reply data)

8.4 Command Control via the Network (continued)

Reply Data format

The connection ID (the data is same as the connection ID data on the sending data format) is attached to the RS-232C commands reply data.

<ACK reply>

Reply	Connection ID
0x06	1 byte

<NAK reply>

Reply	Connection ID
0x15	1 byte

<Error reply>

Reply	Error code	Connection ID
0x1C	2 bytes	1 byte

<Data reply>

Reply	Data	Connection ID
0x1D	2 bytes	1 byte

<Projector busy reply>

Reply	Status code	Connection ID
0x1F	2 bytes	1 byte

<Authentication error reply>

Reply	Authentication Error code		Connection ID
0x1F	0x04	0x00	1 byte

8.4 Command Control via the Network (continued)

Automatic Connection Break

The TCP connection will be automatically disconnected after there is no communication for 30 seconds after being established.

Authentication

The projector does not accept commands without authentication success when authentication is enabled. The projector uses a challenge response type authentication with an MD5 (Message Digest 5) algorithm.
When the projector is using a LAN, a random 8 bytes will be returned if authentication is enabled. Bind this received 8 bytes and the Authentication Password and digest this data with the MD5 algorithm and add this in front of the commands to send.

Following is a sample if the Authentication Password is set to “password” and the random 8 bytes are “a572f60c”.

1) Connect the projector.
2) Receive the random 8 bytes “a572f60c” from the projector.
3) Bind the random 8 bytes “a572f60c” and the Authentication Password “password” and it becomes “a572f60cpassword”.
4) Digest this bind “a572f60cpassword” with MD5 algorithm.
   It will be “e3d97429adffa11bce1f7275813d4bde”.
5) Add this “e3d97429adffa11bce1f7275813d4bde” in front of the commands and send the data.
   Send “e3d97429adffa11bce1f7275813d4bde”+command.
6) When the sending data is correct, the command will be performed and the reply data will be returned. Otherwise, an authentication error will be returned.

NOTE • As for the transmission of the second or subsequent commands, the authentication data can be omitted when the same connection.

8.5 Crestron Connected™

Crestron Connected™ is a multi-user resource management program provided by Crestron Electronics, Inc. It is an application for managing and controlling the projector and other AV devices collectively.
For details of Crestron Connected™, refer to the Crestron® website.

URL: http://www.crestron.com

The following communication interfaces can be used to manage the entire facility.

1) Crestron Fusion RV® / Crestron RoomView® Express / Crestron RoomView® Server Edition
Fusion RV®,RoomView® Express and RoomView® Server Edition are software provided by Crestron Electronics, Inc. They are used for managing all the AV devices, and are also able to communicate with the help desk as well as send out alert messages.
For details of the software, refer to the following website.

URL: http://www.crestron.com/getroomview

2) Crestron e-Control®
Crestron e-Control® is a system controller that can be operated via a web browser. (📖68)

9. Troubleshooting

Phenomenon: Cannot communicate with the projector. (Wired network)

Item to be checked	Solutions
Is the projector turned on?	Turn on the projector.
Is the network device such as a router, etc. turned on?	Turn on the network device.
Is STANDBY MODE set to SAVING?	The network function is not available when STANDBY MODE is set to SAVING. If you want to use the network function in the standby mode, set to NORMAL.
Is LAN cable connected?	Connect the LAN cable.
Is MAC address displayed correctly in the NETWORK INFORMATION – WIRED menu?	Contact your dealer when MAC address on the label put on the projector does not match MAC address displayed in the NETWORK INFORMATION – WIRED menu.
Are the network settings such as IP address set correctly?	Check the network settings in the NETWORK INFORMATION – WIRED menu. Consult with your network administrator for details.
Is firewall or packet filtering set in a router, etc.?	Consult with your network administrator.
Is the same network address set for wireless LAN and wired LAN of the projector?	The same network address cannot be used for wireless LAN and wired LAN. Set different network address for wireless LAN and wired LAN.
Is the wired network adapter of the computer enabled?	Refer to the user's manual for the computer and enable the wired network adapter.

Phenomenon: Cannot communicate with the projector. (Wireless network)

Item to be checked	Solutions
Is the projector turned on?	Turn on the projector.
Is the network device such as an access point, etc. turned on?	Turn on the network device.
Is STANDBY MODE set to SAVING?	The network function is not available when STANDBY MODE is set to SAVING. If you want to use the network function in the standby mode, set to NORMAL.
Are the network settings such as IP address set correctly?	Check the network settings in the NETWORK INFORMATION ─ WIRELESS menu. Consult with your network administrator for details.
Is the USB wireless adapter (optional parts: USB-WL-11N) inserted into **WIRELESS** port of the projector?	Insert the USB wireless adapter.
Is an optional USB wireless adapter used?	The USB wireless adapter available to this projector is optional USB-WL-11N only.
Is MAC address displayed correctly in the NETWORK INFORMATION ─ WIRELESS menu?	When MAC address displayed in NETWORK INFORMATION – WIRELESS menu does not match MAC address engraved on the USB wireless adapter, pull out and insert the USB wireless adapter again. If the problem persists, the USB wireless adapter may be broken. Contact your dealer.
Is LED of the USB wireless adapter blinking?	When LED of the USB wireless adapter does not blink in over 1 minute after inserting, pull out and insert the USB wireless adapter again. If the problem persists, the USB wireless adapter may be broken. Contact your dealer.

Phenomenon: Cannot communicate with the projector. (Wireless network) (continued)

Item to be checked	Solutions
Is firewall or packet filtering set in an access point, etc.?	Consult with your network administrator.
Is the wireless network to connect encrypted?	Set the encryption settings of the projector again and reconnect.
Is an encryption method which is not supported by the projector used?	The followings are encryption methods supported by the projector: · WPA2-PSK(AES) · WPA2-PSK(TKIP) · WPA-PSK(AES) · WPA-PSK(TKIP) · WEP128bit (Available only in INFRASTRUCTURE mode) · WEP64bit (Available only in INFRASTRUCTURE mode) This projector cannot be connected to the wireless network using the encryption methods other than the above.
Is signal strength of wireless network displayed in the SSID SCAN LIST menu weak?	· Put the projector close to the wireless device. · When the projector is near the steel door, the radio wave may not reach to the wireless device. In that case, keep the projector away from the door. · Consult with your network administrator because there may be an interfering wireless device.
Is 5GHz radio wave used?	The USB wireless adapter (USB-WL-11N) does not support 5GHz, but only 2.4GHz.
Is the same network address set for wireless LAN and wired LAN of the projector?	The same network address cannot be used for wireless LAN and wired LAN. Set different network address for wireless LAN and wired LAN.
Is the wireless network adapter of the computer enabled?	Refer to the user's manual for the computer and enable the wireless network adapter.

Phenomenon: Cannot communicate with the projector. (Wireless network) (continued)

Item to be checked	Solutions
Are over 11 devices connected to the projector?	• Confirm the number of the devices connected to the projector. Up to 11 devices can be connected to the projector in Simple Access Point mode. • When the projector is connected to the maximum numbers of devices, connect after disconnecting the device currently connected.
Is the DHCP setting of the computer disabled?	Enable the DHCP setting of the computer. Refer to the user's manual of the computer or wireless LAN device for the setting procedure of network and wireless connection of the computer.
Is it used in SIMPLE ACCESS POINT mode?	It may be better by changing the channel setting.
Dose the IP address overlap with that of the other devices ?	When the IP address overlaps, turn off your WiFi device and turn on again.

Phenomenon: Cannot use wireless LAN and wired LAN at the same time.

Item to be checked	Solutions
Is the same network address set for wireless LAN and wired LAN of the projector?	The same network address cannot be used for wireless LAN and wired LAN. Set different network address for wireless LAN and wired LAN.
Are you trying to access to different network via a router?	Either wired LAN or wireless LAN can access to different network. Set default gateway of either wired LAN or wireless LAN to 0.0.0.0.

Phenomenon: Web(Projector Web Control) is not displayed correctly.

Item to be checked	Solutions
Is the correct URL entered in Web browser?	Enter the IP address of the projector in Web browser.
Is JavaScript enabled?	Enable JavaScript. How to set is different depending on the Web browser. Refer to Help of Web browser, etc. for details.
Is recommended Web browser used?	Recommended Web browsers are Internet Explorer 8/9/10/11. Projector Web Control may not displayed correctly except in recommended browser.
Is the cache of the screen displayed earlier remaining?	Clear the cache. How to set is different depending on the Web browser. Refer to Help of Web browser, etc. for details.

Phenomenon: Crestron e-Control® is not displayed.

Item to be checked	Solutions
Has Adobe® Flash® Player been installed?	Adobe® Flash® Player is required to display Crestron e-Control®. Install Adobe® Flash® Player.
Is Web browser that does not support Adobe® Flash® Player used?	Use a Web browser that supports Adobe® Flash® Player.
Are Crestron e-Control® settings on Network Settings – Other Setup screen of the Projector Web Control disabled?	Enable Crestron e-Control® settings on Network Settings – Other Setup screen of the Projector Web Control.
Is Crestron in Projector Web Control - Network Settings - Common Setup set to OFF?	Set Crestron in Projector Web Control - Network Settings - Common Setup to ON.

Phenomenon: Cannot send an e-mail correctly.

Item to be checked	Solutions
Is a test e-mail sent correctly?	Check if a test e-mail is sent correctly by pressing the [Send Test Mail] button on the Mail Settings screen of the Projector Web Control.
Are e-mail settings correct?	Check the settings on the Mail Settings screen of the Projector Web Control.
Are the settings of Sender e-mail Address correct?	Set valid e-mail address.
Is only e-mail regarding the specific Error/Warning not sent correctly?	Check if the specific Error/Warning is set to be sent on the Mail Settings screen of the Projector Web Control.

Phenomenon: An e-mail does not reach only to the specific address.

Item to be checked	Solutions
Is e-mail address set correctly?	Check the settings on the Mail Settings screen of the Projector Web Control.
Is filtering or forwarding set for the e-mail address in the mail server?	Consult with your network administrator.

Phenomenon: The schedule is not executed correctly.

Item to be checked	Solutions
Is the projector turned on?	Turn on the projector.
Is STANDBY MODE set to SAVING?	The schedule function is not available when STANDBY MODE is set to SAVING. If you want to use the schedule function in the standby mode, set to NORMAL.
Is the time set correctly?	Check the settings of Date and Time.
Is the image data to be displayed in the schedule function registered? (When the event of My Image is set.)	Register the image data to be displayed with the projector by using exclusive application software.
Is the message data to be displayed in the schedule function registered? (When the event of Messenger is set.)	Register the message data to be displayed with the projector by using exclusive application software.
Is the lamp of the projector lighting?	The event of My Image, Messenger and Blank are not executed when the lamp is not lighting. Set the program of the schedule function so that the event of MyImage, Messenger and Blank can be executed when the lamp is lighting.

Item to be checked	Solutions
Is the program to be executed set correctly?	Check the settings of Schedule Settings of the Projector Web Control.
Are there any events set at the same time?	Some events cannot be executed at the same time. Set them to be executed at the different time or change the order.

* The schedule function may not operate correctly depending on the status of the projector.

Phenomenon: The time settings are not correct.

Item to be checked	Solutions
Is battery set?	Set the battery. The battery is considered to be exhausted if the time is off soon after setting date and time. In that case, replace the battery.
Is the date and time set correctly?	Check the settings of Date/Time Settings menu of the Projector Web Control or DATE AND TIME menu of the projector.
Is the projector connected to the network correctly when getting the time via the network?	Connect to the network.
Is SNTP server set correctly when getting the time via the network?	Check the settings of SNTP server. Consult with your network administrator regarding the settings of SNTP server.
Is the time difference set correctly when getting the time via the network?	When getting the time via the network, the correct time is not displayed if the time difference is not set. Set the time difference.

Phenomenon: Cannot control the external device by using Network Bridge.

Item to be checked	Solutions
Is Network Bridge settings enabled?	Check the settings in OPTION – SERVICE – COMMUNICATION – COMMUNICATION TYPE menu.
Is STANDBY MODE set to SAVING?	The Network Bridge is not available when STANDBY MODE is set to SAVING. Set STANDBY MODE to NORMAL, and set NETWORK BRIDGE (WIRELESS/WIRED) in the COMMUNICATION TYPE menu.
Are the serial settings set correctly?	Check the serial settings of the projector and the external device.

10. Warranty and after-sales service

If an abnormal operation (such as smoke, strange odor or excessive sound) should occur, stop using the projector immediately.

If this does not resolve the problem, please consult your dealer or service company. They will tell you what warranty condition is applied.

Please check the following web address where you may find the latest information for this projector.

http://www.hitachi-america.us/projectors

http://www.hitachiserviceeu.com/support/guides/userguides.htm

Trademark acknowledgment

• Microsoft® and Internet Explorer®, Windows®, Windows Vista® are registered trademark of Microsoft Corporation in the U.S. and/or other countries.
• Adobe® and Flash® are registered trademarks of Adobe Systems Incorporated.
• Pentium® is a registered trademark of Intel Corporation.
• JavaScript® is a registered trademark of Sun Microsystems, Inc.
• HDMI™, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
• Crestron®, Crestron e-Control®, e-Control®,Crestron Connected™, Fusion RV®,Crestron RoomView® and RoomView™ are trademarks or registered trademarks of Crestron Electronics, Inc. in the United States and other countries.
• Trademark PJLink is a trademark applied for trademark rights in Japan, the United States of America and other countries and areas.
• DisplayPort is a trademark or registered trademark of Video Electronics Standards Association.
All other trademarks are the properties of their respective owners.